

EGT2
ENGINEERING TRIPOS PART IIA

Monday 30 April 2018 2 to 3.40

Module 3D2

GEOTECHNICAL ENGINEERING II

*Answer not more than **three** questions.*

All questions carry the same number of marks.

*The **approximate** percentage of marks allocated to each part of a question is indicated in the right margin.*

*Write your candidate number **not** your name on the cover sheet.*

STATIONERY REQUIREMENTS

Single-sided script paper

Graph paper

SPECIAL REQUIREMENTS TO BE SUPPLIED FOR THIS EXAM

CUED approved calculator allowed

Attachment: Geotechnical Engineering Databook (19 pages)

Engineering Data Book

10 minutes reading time is allowed for this paper at the start of the exam.

You may not start to read the questions printed on the subsequent pages of this question paper until instructed to do so.

1 The stability of an infinite slope in silty calcareous sand with an angle of 25° is of concern. The silty sand forms a layer 6 m deep on top of a parallel sloping bedrock, see Fig. 1. The silty sand has a critical state friction angle of 35° and a void ratio of 0.8. The maximum and minimum void ratios for the silty sand are 0.95 and 0.6 respectively and its specific gravity is 2.7. Groundwater monitoring over a 12 month period showed that the phreatic surface in the silty sand ran parallel to the bedrock and at an elevation of 4 m above the bedrock in the wet season and 2 m above the bedrock in the dry season.

- (a) Calculate the dry and saturated unit weights of the silty sand layer. [10%]
- (b) Sketch the shear stress-displacement curves for loose and dense sands as observed in a direct shear test. Describe the micromechanics behind the shapes of the curves and discuss the use of the strength parameters in design. [20%]
- (c) Use infinite slope analysis, and other carefully justified assumptions, to determine whether the slope should fail in the dry season or the following wet season, if the corresponding groundwater conditions from the previous monitoring exercise are exactly duplicated. [30%]
- (d) What is the maximum elevation that the phreatic surface can reach above the bedrock before the slope will definitely fail? [40%]




Fig. 1

2 A self-boring pressuremeter test is undertaken in a stiff clay at a depth of 24 m. The water table is at a depth of 2 m. The unit weight of the clay is 19 kN m^{-3} and its critical state friction angle is $\phi_{cs} = 23^\circ$. Results of the test, including an unload-reload loop, are given below in terms of the cavity pressure σ_c and the cavity strain ε_c , which is defined as the radial movement of the pressuremeter divided by the current radius (expressed as a percentage).

Pressure σ_c (kPa)	Cavity strain ε_c (%)
0	0.00
300	0.00
490	0.00
600	0.07
750	0.38
900	0.85
1050	1.47
1120	2.26
1000	2.13
900	1.92
1000	2.00
1125	2.30
1215	3.58
1280	5.02
1350	7.34

- (a) Estimate the coefficient of horizontal earth pressure at rest, K_0 , and speculate regarding the stress history of the clay. [20%]
- (b) Deduce the initial shear modulus, G_i , and the value G_{ur} , from the unload-reload loop data. Comment briefly on the difference, if any, between the two values. [20%]
- (c) Estimate the undrained shear strength of the clay. [30%]
- (d) Estimate the pore pressure at the cavity wall when the pressuremeter pressure reached 1350 kPa. [30%]

3 A clay specimen was retrieved from site and consolidated within a triaxial apparatus to an effective confining stress of 200 kPa. The sample was then subjected to a consolidated drained, CD, compression test and was observed to yield at a deviatoric stress q of 100 kPa before reaching failure at a deviatoric stress of 330 kPa. A sample of the same clay tested in an oedometer gave values $\Gamma = 2.8$, $\lambda = 0.15$ and $\kappa = 0.03$.

(a) Sketch the triaxial effective stress path in p' - q space, labelling the points of yield and failure. Using Cam-clay, estimate both the slope of the critical state line, M , and the maximum stress previously experienced by the sample. [30%]

(b) Sketch the triaxial stress path in v - $\ln(p')$ space and estimate the volumetric strain experienced by the triaxial sample at both yield and failure. [30%]

(c) If the sample had instead been subjected to an undrained CU triaxial test, sketch the stress path in both p' - q and v - $\ln(p')$ space and calculate the deviatoric stress at both yield and failure together with the excess pore pressures at each of these states. [40%]

4 (a) Using the Cam-clay model in simple shear, explain with the aid of sketches how the phenomena of hardening and softening arise for clay soils sheared beyond initial yield and how this relates to the initial overconsolidation ratio of the soil. [40%]

(b) Identical clay slurry samples are consolidated within a simple shear apparatus to a normal effective stress σ'_{max} and are then allowed to swell to an effective stress σ'_o before being sheared under constant normal stress. Use the Simple Shear Cam-clay model to derive algebraic relationships as a function of OCR for:

(i) the peak strength in undrained shear;

(ii) the critical state strength in undrained shear;

(iii) the peak strength in drained shear;

(iv) the critical state strength in drained shear. [30%]

(c) Discuss the importance of these strengths when carrying out stability assessments of clay slopes across a range of OCRs and when designing excavating equipment. [30%]


END OF PAPER

THIS PAGE IS BLANK

Engineering Tripos Part IIA**3D1 & 3D2
Geotechnical Engineering
Data Book 2017-2018**

Contents	Page
General definitions	2
Soil classification	3
Seepage	4
One-dimensional compression	5
One-dimensional consolidation	6
Stress and strain components	7, 8
Elastic stiffness relations	9
Cam Clay	10, 11
Friction and dilation	12, 13, 14
Plasticity; cohesive material	15
Plasticity; frictional material	16
Empirical earth pressure coefficients	17
Cylindrical cavity expansion	17
Infinite slope analysis	17
Shallow foundation capacity	18, 19

General definitions



Specific gravity of solid

$$G_s$$

Voids ratio

$$e = V_v / V_s$$

Specific volume

$$v = V_t / V_s = 1 + e$$

Porosity

$$n = V_v / V_t = e / (1 + e)$$

Water content

$$w = (W_w / W_s)$$

Degree of saturation

$$S_r = V_w / V_v = (w G_s / e)$$

Unit weight of water

$$\gamma_w = 9.81 \text{ kN/m}^3$$

Unit weight of soil

$$\gamma = W_t / V_t = \left(\frac{G_s + S_r e}{1 + e} \right) \gamma_w$$

Buoyant saturated unit weight

$$\gamma' = \gamma - \gamma_w = \left(\frac{G_s - 1}{1 + e} \right) \gamma_w$$

Unit weight of dry solids

$$\gamma_d = W_s / V_t = \left(\frac{G_s}{1 + e} \right) \gamma_w$$

Air volume ratio

$$A = V_a / V_t = \left(\frac{e(1 - S_r)}{1 + e} \right)$$

Soil classification (BS1377)Liquid limit w_L Plastic Limit w_P Plasticity Index $I_p = w_L - w_P$ Liquidity Index $I_L = \frac{w - w_P}{w_L - w_P}$ Activity = $\frac{\text{Plasticity Index}}{\text{Percentage of particles finer than } 2 \mu\text{m}}$ Sensitivity = $\frac{\text{Unconfined compressive strength of an undisturbed specimen}}{\text{Unconfined compressive strength of a remoulded specimen}}$ (at the same water content)*Classification of particle sizes:-*


Boulders	larger than			200 mm
Cobbles	between	200 mm	and	60 mm
Gravel	between	60 mm	and	2 mm
Sand	between	2 mm	and	0.06 mm
Silt	between	0.06 mm	and	0.002 mm
Clay	smaller than	0.002 mm (two microns)		

D equivalent diameter of soil particle

 D_{10} , D_{60} etc. particle size such that 10% (or 60%) etc.) by weight of a soil sample is composed of finer grains. C_U uniformity coefficient D_{60}/D_{10}

Seepage

Flow potential:
(piezometric level)



Total gauge pore water pressure at A: $u = \gamma_w h = \gamma_w (\bar{h} + z)$

B: $u + \Delta u = \gamma_w (h + \Delta h) = \gamma_w (\bar{h} + z + \Delta \bar{h} + \Delta z)$

Excess pore water pressure at A: $\bar{u} = \gamma_w \bar{h}$

B: $\bar{u} + \Delta \bar{u} = \gamma_w (\bar{h} + \Delta \bar{h})$

Hydraulic gradient A \rightarrow B $i = -\frac{\Delta \bar{h}}{\Delta s}$

Hydraulic gradient (3D) $i = -\nabla \bar{h}$

Darcy's law $V = ki$
 V = superficial seepage velocity
 k = coefficient of permeability

Typical permeabilities:

$D_{10} > 10 \text{ mm}$: non-laminar flow
 $10 \text{ mm} > D_{10} > 1 \mu\text{m}$: $k \cong 0.01 (D_{10} \text{ in mm})^2 \text{ m/s}$
 clays : $k \cong 10^{-9} \text{ to } 10^{-11} \text{ m/s}$


Saturated capillary zone

$h_c = \frac{4T}{\gamma_w d}$: capillary rise in tube diameter d , for surface tension T

$h_c \approx \frac{3 \times 10^{-5}}{D_{10}} \text{ m}$: for water at 10°C ; note air entry suction is $u_c = -\gamma_w h_c$

One-Dimensional Compression

• Fitting data



Plastic compression stress σ'_c is taken as the larger of the initial aggregate crushing stress and the historic maximum effective vertical stress. Clay muds are taken to begin with $\sigma'_c \approx 1$ kPa.

Plastic compression (normal compression line, ncl): $v = v_\lambda - \lambda \ln \sigma'$ for $\sigma' = \sigma'_c$

Elastic swelling and recompression line (esrl): $v = v_c + \kappa (\ln \sigma'_c - \ln \sigma'_v)$
 $= v_\kappa - \kappa \ln \sigma'_v$ for $\sigma' < \sigma'_c$

Equivalent parameters for \log_{10} stress scale:

Terzaghi's compression index $C_c = \lambda \log_{10} e$

Terzaghi's swelling index $C_s = \kappa \log_{10} e$

• Deriving confined soil stiffnesses

Secant 1D compression modulus $E_o = (\Delta\sigma' / \Delta\varepsilon)_o$


Tangent 1D plastic compression modulus $E_o = v \sigma' / \lambda$

Tangent 1D elastic compression modulus $E_o = v \sigma' / \kappa$

One-Dimensional Consolidation

Settlement	ρ	$= \int m_v (\Delta u - \bar{u}) dz$	$= \int (\Delta u - \bar{u}) / E_o dz$
Coefficient of consolidation	c_v	$= \frac{k}{m_v \gamma_w}$	$= \frac{kE_o}{\gamma_w}$
Dimensionless time factor	T_v	$= \frac{c_v t}{d^2}$	
Relative settlement	R_v	$= \frac{\rho}{\rho_{ult}}$	

• Solutions for initially rectangular distribution of excess pore pressure



Approximate solution by parabolic isochrones:

Phase (i) $L^2 = 12 c_v t$
 $R_v = \sqrt{\frac{4T_v}{3}}$ for $T_v < 1/12$

Phase (ii) $b = \exp(1/4 - 3T_v)$
 $R_v = [1 - 2/3 \exp(1/4 - 3T_v)]$ for $T_v > 1/12$

Solution by Fourier Series:

T_v	0	0.01	0.02	0.04	0.08	0.15	0.20	0.30	0.40	0.50	0.60	0.80	1.00
R_v	0	0.12	0.17	0.23	0.32	0.45	0.51	0.62	0.70	0.77	0.82	0.89	0.94

Stress and strain components

- **Principle of effective stress (saturated soil)**

$$\text{total stress } \sigma = \text{effective stress } \sigma' + \text{pore water pressure } u$$

- **Principal components of stress and strain**

sign convention	compression positive
total stress	$\sigma_1, \sigma_2, \sigma_3$
effective stress	$\sigma'_1, \sigma'_2, \sigma'_3$
strain	$\varepsilon_1, \varepsilon_2, \varepsilon_3$

- **Simple Shear Apparatus (SSA)** ($\varepsilon_2 = 0$; other principal directions unknown)

The only stresses that are readily available are the shear stress τ and normal stress σ applied to the top platen. The pore pressure u can be controlled and measured, so the normal effective stress σ' can be found. Drainage can be permitted or prevented. The shear strain γ and normal strain ε are measured with respect to the top platen, which is a plane of zero extension. Zero extension planes are often identified with slip surfaces.

$$\text{work increment per unit volume} \quad \delta W = \tau \delta\gamma + \sigma' \delta\varepsilon$$

- **Biaxial Apparatus - Plane Strain (BA-PS)** ($\varepsilon_2 = 0$; rectangular edges along principal axes)

Intermediate principal effective stress σ'_2 , in zero strain direction, is frequently unknown so that all conditions are related to components in the 1-3 plane.

mean total stress	$s = (\sigma_1 + \sigma_3)/2$
mean effective stress	$s' = (\sigma'_1 + \sigma'_3)/2 = s - u$
shear stress	$t = (\sigma'_1 - \sigma'_3)/2 = (\sigma_1 - \sigma_3)/2$

$$\text{volumetric strain} \quad \varepsilon_v = \varepsilon_1 + \varepsilon_3$$

$$\text{shear strain} \quad \varepsilon_\gamma = \varepsilon_1 - \varepsilon_3$$

$$\text{work increment per unit volume} \quad \delta W = \sigma'_1 \delta\varepsilon_1 + \sigma'_3 \delta\varepsilon_3$$

$$\delta W = s' \delta\varepsilon_v + t \delta\varepsilon_\gamma$$

providing that principal axes of strain increment and of stress coincide.

• **Triaxial Apparatus – Axial Symmetry (TA-AS)** (cylindrical element with radial symmetry)


total axial stress	$\sigma_a = \sigma'_a + u$
total radial stress	$\sigma_r = \sigma'_r + u$
total mean normal stress	$p = (\sigma_a + 2\sigma_r)/3$
effective mean normal stress	$p' = (\sigma'_a + 2\sigma'_r)/3 = p - u$
deviatoric stress	$q = \sigma'_a - \sigma'_r = \sigma_a - \sigma_r$
stress ratio	$\eta = q/p'$
axial strain	ϵ_a
radial strain	ϵ_r
volumetric strain	$\epsilon_v = \epsilon_a + 2\epsilon_r$
triaxial shear strain	$\epsilon_s = \frac{2}{3}(\epsilon_a - \epsilon_r)$
work increment per unit volume	$\delta W = \sigma'_a \delta \epsilon_a + 2\sigma'_r \delta \epsilon_r$
	$\delta W = p' \delta \epsilon_v + q \delta \epsilon_s$

Types of triaxial test include:

- isotropic compression* in which p' increases at zero q
- triaxial compression* in which q increases *either* by increasing σ_a *or* by reducing σ_r
- triaxial extension* in which q reduces *either* by reducing σ_a *or* by increasing σ_r

• **Mohr's circle of stress (1–3 plane)**

Sign of convention: compression, and counter-clockwise shear, positive



Poles of planes P: the components of stress on the N plane are given by the intersection N of the Mohr circle with the line PN through P parallel to the plane.

Elastic stiffness relations

These relations apply to tangent stiffnesses of over-consolidated soil, with a state point on some swelling and recompression line (κ -line), and remote from gross plastic yielding.

One-dimensional compression (axial stress and strain increments $d\sigma'$, $d\varepsilon$)

$$\text{compressibility} \quad m_v = \frac{d\varepsilon}{d\sigma'}$$

$$\text{constrained modulus} \quad E_o = \frac{1}{m_v}$$

Physically fundamental parameters

$$\text{shear modulus} \quad G' = \frac{dt}{d\varepsilon_\gamma}$$

$$\text{bulk modulus} \quad K' = \frac{dp'}{d\varepsilon_v}$$

Parameters which can be used for constant-volume deformations

$$\text{undrained shear modulus} \quad G_u = G'$$

$$\text{undrained bulk modulus} \quad K_u = \infty \quad (\text{neglecting compressibility of water})$$

Alternative convenient parameters

$$\text{Young's moduli} \quad E' \text{ (effective), } E_u \text{ (undrained)}$$

$$\text{Poisson's ratios} \quad \nu' \text{ (effective), } \nu_u = 0.5 \text{ (undrained)}$$

Typical value of Poisson's ratio for small changes of stress: $\nu' = 0.2$

$$\text{Relationships:} \quad G = \frac{E}{2(1+\nu)}$$

$$K = \frac{E}{3(1-2\nu)}$$

$$E_o = \frac{E(1-\nu)}{(1+\nu)(1-2\nu)}$$

Cam Clay

- Interchangeable parameters for stress combinations at yield, and plastic strain increments

System	Effective normal stress	Plastic normal strain	Effective shear stress	Plastic shear strain	Critical stress ratio	Plastic normal stress	Critical normal stress
General	σ^*	ε^*	τ^*	γ^*	μ^*_{crit}	σ^*_c	σ^*_{crit}
SSA	σ'	ε	τ	γ	$\tan \phi_{crit}$	σ'_c	σ'_{crit}
BA-PS	s'	ε_v	t	ε_γ	$\sin \phi_{crit}$	s'_c	s'_{crit}
TA-AS	p'	ε_v	q	ε_s	M	p'_c	p'_{crit}

- General equations of plastic work

Plastic work and dissipation

$$\sigma^* \delta\varepsilon^* + \tau^* \delta\gamma^* = \mu^*_{crit} \sigma^* \delta\gamma^*$$

Plastic flow rule – normality

$$\frac{d\tau^*}{d\sigma^*} \cdot \frac{d\gamma^*}{d\varepsilon^*} = -1$$

- General yield surface


$$\frac{\tau^*}{\sigma^*} = \mu^* = \mu^*_{crit} \cdot \ln \left[\frac{\sigma_c^*}{\sigma^*} \right]$$

- Parameter values which fit soil data

	London Clay	Weald Clay	Kaolin	Dog's Bay Sand	Ham River Sand
λ^*	0.161	0.093	0.26	0.334	0.163
κ^*	0.062	0.035	0.05	0.009	0.015
Γ^* at 1 kPa	2.759	2.060	3.767	4.360	3.026
$\sigma^*_{c, virgin}$ kPa	1	1	1	Loose 500 Dense 1500	Loose 2500 Dense 15000
ϕ_{crit}	23°	24°	26°	39°	32°
M_{comp}	0.89	0.95	1.02	1.60	1.29
M_{extn}	0.69	0.72	0.76	1.04	0.90
w_L	0.78	0.43	0.74	-----	-----
w_P	0.26	0.18	0.42	-----	-----
G_s	2.75	2.75	2.61	2.75	2.65

Note: 1) parameters λ^* , κ^* , Γ^* , σ^*_{c} should depend to a small extent on the deformation mode, e.g. SSA, BA-PS, TA-AS, etc. This may be neglected unless further information is given.
 2) Sand which is loose, or loaded cyclically, compacts more than Cam Clay allows.

• The yield surface in (σ^*, τ^*, v) space





ncl: normal compression line

$$v = N - \lambda \ln \sigma^*$$


csl: critical state line

$$v = \Gamma - \lambda \ln \sigma^*$$

where $N = \Gamma + \lambda - \kappa$



• Regions of limiting soil behaviour




Variation of Cam Clay yield surface

Zone D: denser than critical, "dry",
dilation or negative excess pore pressures,
Hvorslev strength envelope,
friction-dilatancy theory,
unstable shear rupture, progressive failure

Zone L: looser than critical, "wet",
compaction or positive excess pore pressures,
Modified Cam Clay yield surface,
stable strain-hardening continuum

Strength of soil: friction and dilation

• Friction and dilatancy: the saw-blade model of direct shear




Intergranular angle of friction at sliding contacts ϕ_μ

Angle of dilation ψ_{\max}

Angle of internal friction $\phi_{\max} = \phi_\mu + \psi_{\max}$

• Friction and dilatancy: secant and tangent strength parameters



Secant angle of internal friction

$$\tau = \sigma' \tan \phi_{\max}$$

$$\phi_{\max} = \phi_{\text{crit}} + \Delta\phi$$


$$\Delta\phi = f(\sigma'_{\text{crit}}/\sigma')$$

typical envelope fitting data:

power curve

$$(\tau/\tau_{\text{crit}}) = (\sigma'/\sigma'_{\text{crit}})^\alpha$$

with $\alpha \approx 0.85$



Tangent angle of shearing envelope

$$\tau = c' + \sigma' \tan \phi'$$

$$c' = f(\sigma'_{\text{crit}})$$

typical envelope:

straight line

$$\tan \phi' = 0.85 \tan \phi_{\text{crit}}$$

$$c' = 0.15 \tau_{\text{crit}}$$

● **Friction and dilation: data of sands**

The inter-granular friction angle of quartz grains, $\phi_{\mu} \approx 26^{\circ}$. Turbulent shearing at a critical state causes ϕ_{crit} to exceed this. The critical state angle of internal friction ϕ_{crit} is a function of the uniformity of particle sizes, their shape, and mineralogy, and is developed at large shear strains irrespective of initial conditions. Typical values of $\phi_{\text{crit}} (\pm 2^{\circ})$ are:

well-graded, angular quartz or feldspar sands	40°
uniform sub-angular quartz sand	36°
uniform rounded quartz sand	32°

Relative density $I_D = \frac{(e_{\text{max}} - e)}{(e_{\text{max}} - e_{\text{min}})}$ where:

e_{max} is the maximum void ratio achievable in quick-tilt test

e_{min} is the minimum void ratio achievable by vibratory compaction

Relative crushability $I_C = \ln(\sigma_c / p')$ where:

σ_c is the aggregate crushing stress, taken to be a material constant, typical values being:
80 000 kPa for quartz silt, 20 000 kPa for quartz sand, 5 000 kPa for carbonate sand.

p' is the mean effective stress at failure which may be taken as approximately equal to the effective stress σ' normal to a shear plane.

Dilatancy contribution to the peak angle of internal friction is $\Delta\phi = (\phi_{\text{max}} - \phi_{\text{crit}}) = f(I_R)$

Relative dilatancy index $I_R = I_D I_C - 1$ where:


$I_R < 0$ indicates compaction, so that I_D increases and $I_R \rightarrow 0$ ultimately at a critical state

$I_R > 4$ to be limited to $I_R = 4$ unless corroborative dilatant strength data is available

The following empirical correlations are then available


plane strain conditions	$(\phi_{\text{max}} - \phi_{\text{crit}})$	=	0.8 ψ_{max}	=	5 I_R degrees
triaxial strain conditions	$(\phi_{\text{max}} - \phi_{\text{crit}})$	=	3 I_R degrees		
all conditions	$(-\delta\varepsilon_v / \delta\varepsilon_1)_{\text{max}}$	=	0.3 I_R		

The resulting peak strength envelope for triaxial tests on a quartz sand at an initial relative density $I_D = 1$ is shown below for the limited stress range 10 - 400 kPa:



$$\phi_{\text{max}} > \phi_{\text{crit}} + 9^{\circ} \quad \text{for } I_D = 1, \sigma' = 400 \text{ kPa}$$

• Mobilised (secant) angle of shearing ϕ in the 1 – 3 plane




$$\begin{aligned} \sin \phi &= TS/OS \\ &= \frac{(\sigma'_1 - \sigma'_3)/2}{(\sigma'_1 + \sigma'_3)/2} \\ \left[\frac{\sigma'_1}{\sigma'_3} \right] &= \frac{(1 + \sin \phi)}{(1 - \sin \phi)} \end{aligned}$$

Angle of shearing resistance:

at peak strength ϕ_{\max} at $\left[\frac{\sigma'_1}{\sigma'_3} \right]_{\max}$

at critical state ϕ_{crit} after large shear strains

• Mobilised angle of dilation in plane strain ψ in the 1 – 3 plane



$$\begin{aligned} \sin \psi &= VO/VZ \\ &= -\frac{(\delta\epsilon_1 + \delta\epsilon_3)/2}{(\delta\epsilon_1 - \delta\epsilon_3)/2} \\ &= -\frac{\delta\epsilon_v}{\delta\epsilon_\gamma} \end{aligned}$$

$$\left[\frac{\delta\epsilon_1}{\delta\epsilon_3} \right] = -\frac{(1 - \sin \psi)}{(1 + \sin \psi)}$$

at peak strength $\psi = \psi_{\max}$ at $\left[\frac{\sigma'_1}{\sigma'_3} \right]_{\max}$

at critical state $\psi = 0$ since volume is constant

Plasticity: Cohesive material $\tau_{max} = c_u$ (or s_u)

• Limiting stresses

Tresca $|\sigma_1 - \sigma_3| = q_u = 2c_u$

von Mises $(\sigma_1 - p)^2 + (\sigma_2 - p)^2 + (\sigma_3 - p)^2 = \frac{2}{3} q_u^2 = 2c_u^2$

where q_u is the undrained triaxial compression strength, and c_u is the undrained plane shear strength.


Dissipation per unit volume in plane strain deformation following either Tresca or von Mises,

$$\delta D = c_u \delta \epsilon_\gamma$$

For a relative displacement x across a slip surface of area A mobilising shear strength c_u , this becomes

$$D = Ac_u x$$

• Stress conditions across a discontinuity




Rotation of major principal stress θ

$$s_B - s_A = \Delta s = 2c_u \sin \theta$$

$$\sigma_{1B} - \sigma_{1A} = 2c_u \sin \theta$$

In limit with $\theta \rightarrow 0$

$$ds = 2c_u d\theta$$



Useful example:

$$\theta = 30^\circ$$

$$\sigma_{1B} - \sigma_{1A} = c_u$$

$$\tau_D / c_u = 0.87$$

σ_{1A} = major principal stress in zone A

σ_{1B} = major principal stress in zone B

Plasticity: Frictional material $(\tau/\sigma')_{\max} = \tan \phi$

• **Limiting stresses**

$$\sin \phi = (\sigma'_{1f} - \sigma'_{3f}) / (\sigma'_{1f} + \sigma'_{3f}) = (\sigma_{1f} - \sigma_{3f}) / (\sigma_{1f} + \sigma_{3f} - 2u_s)$$

where σ'_{1f} and σ'_{3f} are the major and minor principal effective stresses at failure, σ_{1f} and σ_{3f} are the major and minor principle total stresses at failure, and u_s is the steady state pore pressure.

Active pressure:

$$\sigma'_v > \sigma'_h$$

$$\sigma'_1 = \sigma'_v \text{ (assuming principal stresses are horizontal and vertical)}$$

$$\sigma'_3 = \sigma'_h$$

$$K_a = (1 - \sin \phi) / (1 + \sin \phi)$$

Passive pressure:


$$\sigma'_h > \sigma'_v$$

$$\sigma'_1 = \sigma'_h \text{ (assuming principal stresses are horizontal and vertical)}$$

$$\sigma'_3 = \sigma'_v$$

$$K_p = (1 + \sin \phi) / (1 - \sin \phi) = 1 / K_a$$

• **Stress conditions across a discontinuity**




Rotation of major principal stress

$$\theta = \pi/2 - \Omega$$

σ_{1A} = major principal stress in zone A

σ_{1B} = major principal stress in zone B

$$\tan \delta = \tau_D / \sigma'_D$$



$$\sin \Omega = \sin \delta / \sin \phi$$

$$s'_B / s'_A = \sin(\Omega + \delta) / \sin(\Omega - \delta)$$

In limit, $d\theta \rightarrow 0$ and $\delta \rightarrow \phi$

$$ds' = 2s' \cdot d\theta \tan \phi$$

Integration gives $s'_B / s'_A = \exp(2\theta \tan \phi)$

Empirical earth pressure coefficients following one-dimensional strain

Coefficient of earth pressure in 1D plastic compression (normal compression)

$$K_{o,nc} = 1 - \sin \phi_{crit}$$

Coefficient of earth pressure during a 1D unloading-reloading cycle (overconsolidated soil)

$$K_o = K_{o,nc} \left[1 + \frac{(n-1)(n_{max}^\alpha - 1)}{(n_{max} - 1)} \right]$$

where n is current overconsolidation ratio (OCR) defined as $\sigma'_{v,max} / \sigma'_v$

n_{max} is maximum historic OCR defined as $\sigma'_{v,max} / \sigma'_{v,min}$

α is to be taken as $1.2 \sin \phi_{crit}$

Cylindrical cavity expansion

Expansion $\delta A = A - A_0$ caused by increase of pressure $\delta \sigma_c = \sigma_c - \sigma_0$

At radius r : small displacement $\rho = \frac{\delta A}{2\pi r}$


small shear strain $\gamma = \frac{2\rho}{r}$

Radial equilibrium: $r \frac{d\sigma_r}{dr} + \sigma_r - \sigma_\theta = 0$

Elastic expansion (small strains) $\delta \sigma_c = G \frac{\delta A}{A}$

Undrained plastic-elastic expansion $\delta \sigma_c = c_u \left[1 + \ln \frac{G}{c_u} + \ln \frac{\delta A}{A} \right]$

Infinite slope analysis



$$\begin{aligned} u &= \gamma_w z_w \cos^2 \beta \\ \sigma &= \gamma z \cos^2 \beta \\ \sigma' &= (\gamma z - \gamma_w z_w) \cos^2 \beta \\ \tau &= \gamma z \cos \beta \sin \beta \end{aligned}$$

$$\tan \phi_{mob} = \frac{\tau}{\sigma'} = \frac{\tan \beta}{\left(1 - \frac{\gamma_w z_w}{\gamma z}\right)}$$

Shallow foundation design

Tresca soil, with undrained strength s_u

Vertical loading

The vertical bearing capacity, q_f , of a shallow foundation for undrained loading (Tresca soil) is:

$$\frac{V_{ult}}{A} = q_f = s_c d_c N_c s_u + \gamma h$$

V_{ult} and A are the ultimate vertical load and the foundation area, respectively. h is the embedment of the foundation base and γ (or γ') is the appropriate density of the overburden.

The exact bearing capacity factor N_c for a plane strain surface foundation (zero embedment) on uniform soil is:

$$N_c = 2 + \pi \quad (\text{Prandtl, 1921})$$

Shape correction factor:

For a rectangular footing of length L and breadth B (Eurocode 7):

$$s_c = 1 + 0.2 B / L$$

The exact solution for a rough circular foundation ($D = B = L$) is $q_f = 6.05s_u$, hence $s_c = 1.18 \sim 1.2$.

Embedment correction factor:

A fit to Skempton's (1951) embedment correction factors, for an embedment of h , is:

$$d_c = 1 + 0.33 \tan^{-1} (h/B) \quad (\text{or } h/D \text{ for a circular foundation})$$

Combined V-H loading

A curve fit to Green's lower bound plasticity solution for V-H loading is:

$$\text{If } V/V_{ult} > 0.5: \quad \frac{V}{V_{ult}} = \frac{1}{2} + \frac{1}{2} \sqrt{1 - \frac{H}{H_{ult}}} \quad \text{or} \quad \frac{H}{H_{ult}} = 1 - \left(2 \frac{V}{V_{ult}} - 1 \right)^2$$

$$\text{If } V/V_{ult} < 0.5: \quad H = H_{ult} = B s_u$$

Combined V-H-M loading

With lift-off: combined Green-Meyerhof

$$\text{Without lift-off:} \quad \left(\frac{V}{V_{ult}} \right)^2 + \left[\frac{M}{M_{ult}} \left(1 - 0.3 \frac{H}{H_{ult}} \right) \right]^2 + \left| \left(\frac{H}{H_{ult}} \right)^3 \right| - 1 = 0 \quad (\text{Taiebet \& Carter 2000})$$

Frictional (Coulomb) soil, with friction angle ϕ

Vertical loading

The vertical bearing capacity, q_f , of a shallow foundation under drained loading (Coulomb soil) is:

$$\frac{V_{ult}}{A} = q_f = s_q N_q \sigma'_{v0} + s_\gamma N_\gamma \frac{\gamma' B}{2}$$

The bearing capacity factors N_q and N_γ account for the capacity arising from surcharge and self-weight of the foundation soil respectively. σ'_{v0} is the in situ effective stress acting at the level of the foundation base.

For a strip footing on weightless soil, the exact solution for N_q is:

$$N_q = \tan^2(\pi/4 + \phi/2) e^{(\pi \tan \phi)} \quad (\text{Prandtl 1921})$$

An empirical relationship to estimate N_γ from N_q is (Eurocode 7):

$$N_\gamma = 2 (N_q - 1) \tan \phi$$

Curve fits to exact solutions for $N_\gamma = f(\phi)$ are (Davis & Booker 1971):

$$\text{Rough base:} \quad N_\gamma = 0.1054 e^{9.6\phi}$$

$$\text{Smooth base:} \quad N_\gamma = 0.0663 e^{9.3\phi}$$

Shape correction factors:

For a rectangular footing of length L and breadth B (Eurocode 7):

$$s_q = 1 + (B \sin \phi) / L$$

$$s_\gamma = 1 - 0.3 B / L$$

For circular footings take $L = B$.

Combined V-H loading

The Green/Sokolovski lower bound solution gives a V-H failure surface.

Combined V-H-M loading

With lift-off- drained conditions - use Butterfield & Gottardi (1994) failure surface shown above

$$\left[\frac{H/V_{ult}}{t_h} \right]^2 + \left[\frac{M/BV_{ult}}{t_m} \right]^2 + \left[\frac{2C(M/BV_{ult})(H/V_{ult})}{t_h t_m} \right] = \left[\frac{V}{V_{ult}} \left(1 - \frac{V}{V_{ult}} \right) \right]^2$$

$$\text{where} \quad C = \tan \left(\frac{2\rho(t_h - t_m)(t_h + t_m)}{2t_h t_m} \right) \quad (\text{Butterfield \& Gottardi, 1994})$$

Typically, $t_h \sim 0.5$, $t_m \sim 0.4$ and $\rho \sim 15^\circ$. Note that t_h is the friction coefficient, $H/V = \tan \phi$, during sliding.

