

EGT2  
ENGINEERING TRIPOS PART IIA

---

Wednesday 28 April 2021 9.00 to 10.40

---

**Module 3D2**

**GEOTECHNICAL ENGINEERING II**

*Answer not more than **three** questions.*

*All questions carry the same number of marks.*

*The **approximate** percentage of marks allocated to each part of a question is indicated in the right margin.*

*Write your candidate number **not** your name on the cover sheet and at the top of each answer sheet.*

**STATIONERY REQUIREMENTS**

Write on single-sided paper.

**SPECIAL REQUIREMENTS TO BE SUPPLIED FOR THIS EXAM**

CUED approved calculator allowed.

Attachment: 3D1 & 3D2 Geotechnical Engineering Databook, 21 pages.

You are allowed access to the electronic version of the Engineering Data Books.

**10 minutes reading time is allowed for this paper at the start of the exam.**

**The time taken for scanning/uploading answers is 15 minutes.**

**Your script is to be uploaded as a single consolidated pdf containing all answers.**

1 A clay sample was recovered from a construction site at a depth of 10 m in order to perform testing to determine soil properties. The unit weight of the clay was  $\gamma = 17 \text{ kNm}^{-3}$  and the site investigation showed this to be approximately constant with depth. The specific gravity of the clay was  $G_s = 2.6$ . The water table was at a depth of 2 m. Use the Cam-Clay model to answer the following questions:

(a) A specimen was consolidated isotropically to a stress equal to the *in-situ* vertical effective stress. The specimen was then subjected to drained triaxial compression.

(i) The specimen yielded at a deviatoric stress of 50 kPa and failed at critical state when the deviatoric stress was 120 kPa. Calculate the maximum preconsolidation pressure  $p'_c$  and the critical stress ratio  $M$ . [30%]

(ii) After isotropic consolidation, the sample was found to be saturated with a water content of 50%. At yield, the sample had suffered a volumetric strain of 0.2% and at failure a volumetric strain of 2.5%. Plot the state path in  $(v:\ln p')$  space and calculate values of  $\kappa$  and  $\lambda$ . [35%]

(b) What yield and ultimate strengths would be expected if a sample of the soil consolidated to 120 kPa was tested in undrained triaxial compression, and what would the pore pressures be at these states? [35%]

2 A long tunnel (radius  $R$ , axis depth  $z$ ) has to be constructed in a deposit of clay with unit weight  $\gamma$ . Isotropic conditions can be assumed.

(a) Describe with appropriate sketches how values of undrained shear strength  $s_u$  and elastic shear modulus  $G$  can be determined from the results of a self-boring pressuremeter test carried out at the depth of the tunnel axis. Give two methods by which  $s_u$  can be estimated. [20%]

(b) Assuming that tunnel construction can be approximated to the complete unloading of a cylindrical cavity under undrained conditions (unlined tunnel), show that the radial ground movement  $\rho_c$  at the tunnel boundary is given by:

$$\rho_c = \frac{R}{2} \frac{s_u}{G} \exp\left(\frac{\gamma z}{s_u} - 1\right)$$

[30%]

(c) Assume that the clay has unit weight  $\gamma = 20 \text{ kNm}^{-3}$ , undrained shear strength  $s_u = 80 \text{ kPa}$  and elastic shear modulus  $G = 20 \text{ MPa}$ . Decide whether a tunnel with radius  $R = 4 \text{ m}$  at a depth  $z = 20 \text{ m}$  requires support to be excavated safely and justify your answer. [10%]

(d) If the average radial stress measured on the smooth lining of the tunnel in (c) immediately after excavation is  $\sigma_r = 240 \text{ kPa}$ , compute the settlement at the crown. [20%]

(e) A pipeline runs with its axis perpendicular to that of the tunnel, at 5 m below ground level. Assuming that the pipeline is of small diameter and fully flexible (*i.e.*, deforming with the ground), estimate the maximum settlement of the pipeline. [20%]

3 A long slope with an angle of  $27^\circ$  has to be formed in a sub-angular quartz sand with minimum and maximum void ratios  $e_{\min} = 0.40$  and  $e_{\max} = 0.85$ . From the surface to a depth of 3 m, the sand has been compacted to obtain an *in-situ* void ratio  $e = 0.50$ . Underneath this surface layer, the soil is looser, with an estimated void ratio  $e = 0.65$  (see Fig. 1). The critical state friction angle of the sand is  $\phi'_{cs} = 34^\circ$  and its specific gravity is  $G_s = 2.65$ .




Fig. 1

- (a) Find the dry and saturated unit weights of the soil in the surface layer and looser base layer. [5%
- (b) If the slope is dry, find the stress state of the soil at the top of the base layer. Plot the stress state in  $(\sigma':\tau)$  space and discuss whether the slope is stable or not by considering the strength of the soil. [25%




Fig. 2

- (c) After heavy rain, the water table rises to a depth of 0.5 m, as shown in Fig. 2. Seepage is parallel to the ground surface. Discuss whether the slope is stable or not. [25%

(d) To what depth below the surface should the water table rise for the slope to definitely fail? [25%]

(e) If the base layer is lightly overconsolidated clay rather than sand, what evaluation would you carry out to check the stability of the slope? [20%]

4 A smooth embedded wall retains an 8 m deep excavation in clay, as shown in Fig. 3. The coefficient of earth pressure at rest is  $K_0 = 1$  and the groundwater table is 1 m below ground surface. The clay has unit weight  $\gamma = 20 \text{ kNm}^{-3}$ , undrained shear strength  $s_u = 70 \text{ kPa}$ , and friction angle  $\varphi' = 23^\circ$ . On the excavated side, a retaining system provides a support pressure  $p_s$ .




Fig. 3


- (a) Assume the support pressure is  $p_s = 100 \text{ kPa}$ . Compute the safety factor in undrained conditions at a depth of 8 m below ground surface on the retained side (point A in Fig. 3), and sketch the total and effective stress paths in  $(\sigma_h:\sigma_v)$  and  $(s:t)$  spaces. [25%]
- (b) What will happen in the long term, after full dissipation of the excess pore water pressures? [10%]
- (c) Sketch the total and effective stress paths in  $(\sigma_h:\sigma_v)$  and  $(s:t)$  spaces for a support pressure  $p_s = 20 \text{ kPa}$ . Will the soil at A fail in the short term if the support pressure is  $p_s = 20 \text{ kPa}$ ? [30%]
- (d) Sketch the expected curves of  $t:\epsilon_\gamma$  and  $u:\epsilon_\gamma$  for point A in case (c). [20%]
- (e) Use the above to discuss the evolution of the safety factor with time for excavation in clay. [15%]

**END OF PAPER**

**Engineering Tripos Part IIA****3D1 & 3D2  
Geotechnical Engineering  
Data Book 2019-2020**

<b>Contents</b>	<b>Page</b>
General definitions	2
Soil classification	3
Seepage	4
One-dimensional compression	5
One-dimensional consolidation	6
Stress and strain components	7, 8
Elastic stiffness relations	9
Cam Clay	10, 11
Friction and dilation	12, 13, 14
Plasticity; cohesive material	15
Plasticity; frictional material	16
Empirical earth pressure coefficients	17
Cylindrical cavity expansion	17
Infinite slope analysis	17
Shallow foundation capacity	18- 19
Settlement of Shallow Foundations	20-21

## General definitions



Specific gravity of solid

$$G_s$$

Voids ratio

$$e = V_v / V_s$$

Specific volume

$$v = V_t / V_s = 1 + e$$

Porosity

$$n = V_v / V_t = e / (1 + e)$$

Water content

$$w = (W_w / W_s)$$

Degree of saturation

$$S_r = V_w / V_v = (w G_s / e)$$

Unit weight of water

$$\gamma_w = 9.81 \text{ kN/m}^3$$

Unit weight of soil

$$\gamma = W_t / V_t = \left( \frac{G_s + S_r e}{1 + e} \right) \gamma_w$$

Buoyant saturated unit weight

$$\gamma' = \gamma - \gamma_w = \left( \frac{G_s - 1}{1 + e} \right) \gamma_w$$

Unit weight of dry solids

$$\gamma_d = W_s / V_t = \left( \frac{G_s}{1 + e} \right) \gamma_w$$

Air volume ratio

$$A = V_a / V_t = \left( \frac{e(1 - S_r)}{1 + e} \right)$$



**Soil classification (BS1377)**Liquid limit  $w_L$ Plastic Limit  $w_P$ Plasticity Index  $I_P = w_L - w_P$ Liquidity Index  $I_L = \frac{w - w_P}{w_L - w_P}$ Activity =  $\frac{\text{Plasticity Index}}{\text{Percentage of particles finer than } 2 \mu\text{m}}$ Sensitivity =  $\frac{\text{Unconfined compressive strength of an undisturbed specimen}}{\text{Unconfined compressive strength of a remoulded specimen}}$  (at the same water content)*Classification of particle sizes:-*


Boulders	larger than			200 mm
Cobbles	between	200 mm	and	60 mm
Gravel	between	60 mm	and	2 mm
Sand	between	2 mm	and	0.06 mm
Silt	between	0.06 mm	and	0.002 mm
Clay	smaller than	0.002 mm (two microns)		

D equivalent diameter of soil particle

 $D_{10}$ ,  $D_{60}$  etc. particle size such that 10% (or 60%) etc.) by weight of a soil sample is composed of finer grains. $C_U$  uniformity coefficient  $D_{60}/D_{10}$

## Seepage

Flow potential:  
(piezometric level)



Total gauge pore water pressure at A:  $u = \gamma_w h = \gamma_w (\bar{h} + z)$

$$\text{B: } u + \Delta u = \gamma_w (h + \Delta h) = \gamma_w (\bar{h} + z + \Delta \bar{h} + \Delta z)$$

Excess pore water pressure at A:  $\bar{u} = \gamma_w \bar{h}$

$$\text{B: } \bar{u} + \Delta \bar{u} = \gamma_w (\bar{h} + \Delta \bar{h})$$

Hydraulic gradient A  $\rightarrow$  B  $i = -\frac{\Delta \bar{h}}{\Delta s}$

Hydraulic gradient (3D)  $i = -\nabla \bar{h}$

Darcy's law  $V = ki$

$V$  = superficial seepage velocity

$k$  = coefficient of permeability

Typical permeabilities:

$D_{10} > 10 \text{ mm}$	:	non-laminar flow
$10 \text{ mm} > D_{10} > 1 \mu\text{m}$	:	$k \cong 0.01 (D_{10} \text{ in mm})^2 \text{ m/s}$
clays	:	$k \cong 10^{-9} \text{ to } 10^{-11} \text{ m/s}$


Saturated capillary zone

$$h_c = \frac{4T}{\gamma_w d} \quad : \quad \text{capillary rise in tube diameter } d, \text{ for surface tension } T$$

$$h_c \approx \frac{3 \times 10^{-5}}{D_{10}} \text{ m} \quad : \quad \text{for water at } 10^\circ\text{C}; \text{ note air entry suction is } u_c = -\gamma_w h_c$$

## One-Dimensional Compression

### • Fitting data



Plastic compression stress  $\sigma'_c$  is taken as the larger of the initial aggregate crushing stress and the historic maximum effective vertical stress. Clay muds are taken to begin with  $\sigma'_c \approx 1$  kPa.

Plastic compression (normal compression line, ncl):  $v = v_\lambda - \lambda \ln \sigma'$  for  $\sigma' = \sigma'_c$

Elastic swelling and recompression line (esrl):  
 $v = v_c + \kappa (\ln \sigma'_c - \ln \sigma'_v)$   
 $= v_\kappa - \kappa \ln \sigma'_v$  for  $\sigma' < \sigma'_c$

Equivalent parameters for  $\log_{10}$  stress scale:

Terzaghi's compression index  $C_c = \lambda \log_{10} e$

Terzaghi's swelling index  $C_s = \kappa \log_{10} e$

### • Deriving confined soil stiffnesses

Secant 1D compression modulus  $E_o = (\Delta \sigma' / \Delta \epsilon)_o$


Tangent 1D plastic compression modulus  $E_o = v \sigma' / \lambda$

Tangent 1D elastic compression modulus  $E_o = v \sigma' / \kappa$

## One-Dimensional Consolidation

Settlement	$\rho$	$= \int m_v (\Delta u - \bar{u}) dz$	$= \int (\Delta u - \bar{u}) / E_o dz$
Coefficient of consolidation	$c_v$	$= \frac{k}{m_v \gamma_w}$	$= \frac{kE_o}{\gamma_w}$
Dimensionless time factor	$T_v$	$= \frac{c_v t}{d^2}$	
Relative settlement	$R_v$	$= \frac{\rho}{\rho_{ult}}$	

• Solutions for initially rectangular distribution of excess pore pressure



Approximate solution by parabolic isochrones:

Phase (i)  $L^2 = 12 c_v t$   
 $R_v = \sqrt{\frac{4T_v}{3}}$  for  $T_v < 1/12$

Phase (ii)  $b = \exp(1/4 - 3T_v)$   
 $R_v = [1 - 2/3 \exp(1/4 - 3T_v)]$  for  $T_v > 1/12$

Solution by Fourier Series:

$T_v$	0	0.01	0.02	0.04	0.08	0.15	0.20	0.30	0.40	0.50	0.60	0.80	1.00
$R_v$	0	0.12	0.17	0.23	0.32	0.45	0.51	0.62	0.70	0.77	0.82	0.89	0.94

## Stress and strain components

- **Principle of effective stress (saturated soil)**

$$\text{total stress } \sigma = \text{effective stress } \sigma' + \text{pore water pressure } u$$

- **Principal components of stress and strain**

sign convention	compression positive
total stress	$\sigma_1, \sigma_2, \sigma_3$
effective stress	$\sigma'_1, \sigma'_2, \sigma'_3$
strain	$\varepsilon_1, \varepsilon_2, \varepsilon_3$

- **Simple Shear Apparatus (SSA)** ( $\varepsilon_2 = 0$ ; other principal directions unknown)

The only stresses that are readily available are the shear stress  $\tau$  and normal stress  $\sigma$  applied to the top platen. The pore pressure  $u$  can be controlled and measured, so the normal effective stress  $\sigma'$  can be found. Drainage can be permitted or prevented. The shear strain  $\gamma$  and normal strain  $\varepsilon$  are measured with respect to the top platen, which is a plane of zero extension. Zero extension planes are often identified with slip surfaces.

$$\text{work increment per unit volume} \quad \delta W = \tau \delta\gamma + \sigma' \delta\varepsilon$$

- **Biaxial Apparatus - Plane Strain (BA-PS)** ( $\varepsilon_2 = 0$ ; rectangular edges along principal axes)

Intermediate principal effective stress  $\sigma'_2$ , in zero strain direction, is frequently unknown so that all conditions are related to components in the 1-3 plane.

mean total stress	$s = (\sigma_1 + \sigma_3)/2$
mean effective stress	$s' = (\sigma'_1 + \sigma'_3)/2 = s - u$
shear stress	$t = (\sigma'_1 - \sigma'_3)/2 = (\sigma_1 - \sigma_3)/2$

volumetric strain	$\varepsilon_v = \varepsilon_1 + \varepsilon_3$
shear strain	$\varepsilon_\gamma = \varepsilon_1 - \varepsilon_3$

$$\text{work increment per unit volume} \quad \delta W = \sigma'_1 \delta\varepsilon_1 + \sigma'_3 \delta\varepsilon_3$$

$$\delta W = s' \delta\varepsilon_v + t \delta\varepsilon_\gamma$$

providing that principal axes of strain increment and of stress coincide.

• **Triaxial Apparatus – Axial Symmetry (TA-AS)** (cylindrical element with radial symmetry)


total axial stress	$\sigma_a = \sigma'_a + u$
total radial stress	$\sigma_r = \sigma'_r + u$
total mean normal stress	$p = (\sigma_a + 2\sigma_r)/3$
effective mean normal stress	$p' = (\sigma'_a + 2\sigma'_r)/3 = p - u$
deviatoric stress	$q = \sigma'_a - \sigma'_r = \sigma_a - \sigma_r$
stress ratio	$\eta = q/p'$
axial strain	$\epsilon_a$
radial strain	$\epsilon_r$
volumetric strain	$\epsilon_v = \epsilon_a + 2\epsilon_r$
triaxial shear strain	$\epsilon_s = \frac{2}{3}(\epsilon_a - \epsilon_r)$
work increment per unit volume	$\delta W = \sigma'_a \delta \epsilon_a + 2\sigma'_r \delta \epsilon_r$
	$\delta W = p' \delta \epsilon_v + q \delta \epsilon_s$

Types of triaxial test include:

- isotropic compression* in which  $p'$  increases at zero  $q$
- triaxial compression* in which  $q$  increases *either* by increasing  $\sigma_a$  *or* by reducing  $\sigma_r$
- triaxial extension* in which  $q$  reduces *either* by reducing  $\sigma_a$  *or* by increasing  $\sigma_r$

• **Mohr's circle of stress (1–3 plane)**

Sign of convention: compression, and counter-clockwise shear, positive



*Poles of planes P* : the components of stress on the N plane are given by the intersection N of the Mohr circle with the line PN through P parallel to the plane.

## Elastic stiffness relations

These relations apply to tangent stiffnesses of over-consolidated soil, with a state point on some swelling and recompression line ( $\kappa$ -line), and remote from gross plastic yielding.

One-dimensional compression (axial stress and strain increments  $d\sigma'$ ,  $d\varepsilon$ )

$$\text{compressibility} \quad m_v = \frac{d\varepsilon}{d\sigma'}$$

$$\text{constrained modulus} \quad E_o = \frac{1}{m_v}$$

Physically fundamental parameters

$$\text{shear modulus} \quad G' = \frac{dt}{d\varepsilon_\gamma}$$

$$\text{bulk modulus} \quad K' = \frac{dp'}{d\varepsilon_v}$$

Parameters which can be used for constant-volume deformations

$$\text{undrained shear modulus} \quad G_u = G'$$

$$\text{undrained bulk modulus} \quad K_u = \infty \quad (\text{neglecting compressibility of water})$$

Alternative convenient parameters

$$\text{Young's moduli} \quad E' \text{ (effective), } E_u \text{ (undrained)}$$

$$\text{Poisson's ratios} \quad \nu' \text{ (effective), } \nu_u = 0.5 \text{ (undrained)}$$

Typical value of Poisson's ratio for small changes of stress:  $\nu' = 0.2$

$$\text{Relationships:} \quad G = \frac{E}{2(1+\nu)}$$

$$K = \frac{E}{3(1-2\nu)}$$

$$E_o = \frac{E(1-\nu)}{(1+\nu)(1-2\nu)}$$

## Cam Clay

- Interchangeable parameters for stress combinations at yield, and plastic strain increments

System	Effective normal stress	Plastic normal strain	Effective shear stress	Plastic shear strain	Critical stress ratio	Plastic normal stress	Critical normal stress
General	$\sigma^*$	$\varepsilon^*$	$\tau^*$	$\gamma^*$	$\mu^*_{crit}$	$\sigma^*_c$	$\sigma^*_{crit}$
SSA	$\sigma'$	$\varepsilon$	$\tau$	$\gamma$	$\tan \phi_{crit}$	$\sigma'_c$	$\sigma'_{crit}$
BA-PS	$s'$	$\varepsilon_v$	$t$	$\varepsilon_\gamma$	$\sin \phi_{crit}$	$s'_c$	$s'_{crit}$
TA-AS	$p'$	$\varepsilon_v$	$q$	$\varepsilon_s$	$M$	$p'_c$	$p'_{crit}$

- General equations of plastic work

Plastic work and dissipation

$$\sigma^* \delta\varepsilon^* + \tau^* \delta\gamma^* = \mu^*_{crit} \sigma^* \delta\gamma^*$$

Plastic flow rule – normality

$$\frac{d\tau^*}{d\sigma^*} \cdot \frac{d\gamma^*}{d\varepsilon^*} = -1$$

- General yield surface

$$\frac{\tau^*}{\sigma^*} = \mu^* = \mu^*_{crit} \cdot \ln \left[ \frac{\sigma^*_c}{\sigma^*} \right]$$


- Parameter values which fit soil data

	London Clay	Weald Clay	Kaolin	Dog's Bay Sand	Ham River Sand
$\lambda^*$	0.161	0.093	0.26	0.334	0.163
$\kappa^*$	0.062	0.035	0.05	0.009	0.015
$\Gamma^*$ at 1 kPa	2.759	2.060	3.767	4.360	3.026
$\sigma^*_{c, virgin}$ kPa	1	1	1	Loose 500 Dense 1500	Loose 2500 Dense 15000
$\phi_{crit}$	23°	24°	26°	39°	32°
$M_{comp}$	0.89	0.95	1.02	1.60	1.29
$M_{extn}$	0.69	0.72	0.76	1.04	0.90
$w_L$	0.78	0.43	0.74	-----	-----
$w_P$	0.26	0.18	0.42	-----	-----
$G_s$	2.75	2.75	2.61	2.75	2.65

Note: 1) parameters  $\lambda^*$ ,  $\kappa^*$ ,  $\Gamma^*$ ,  $\sigma^*_{c, virgin}$  should depend to a small extent on the deformation mode, e.g. SSA, BA-PS, TA-AS, etc. This may be neglected unless further information is given.  
 2) Sand which is loose, or loaded cyclically, compacts more than Cam Clay allows.



• The yield surface in  $(\sigma^*, \tau^*, v)$  space





ncl: normal compression line

$$v = N - \lambda \ln \sigma^*$$

csl: critical state line


$$v = \Gamma - \lambda \ln \sigma^*$$

where  $N = \Gamma + \lambda - \kappa$



• Regions of limiting soil behaviour

Variation of Cam Clay yield surface




Zone D: denser than critical, “dry”,  
dilation or negative excess pore pressures,  
Hvorslev strength envelope,  
friction-dilatancy theory,  
unstable shear rupture, progressive failure

Zone L: looser than critical, “wet”,  
compaction or positive excess pore pressures,  
Modified Cam Clay yield surface,  
stable strain-hardening continuum

## Strength of soil: friction and dilation

- Friction and dilatancy: the saw-blade model of direct shear




Intergranular angle of friction at sliding contacts  $\phi_\mu$

Angle of dilation  $\psi_{\max}$

Angle of internal friction  $\phi_{\max} = \phi_\mu + \psi_{\max}$


- Friction and dilatancy: secant and tangent strength parameters



Secant angle of internal friction

$$\begin{aligned} \tau &= \sigma' \tan \phi_{\max} \\ \phi_{\max} &= \phi_{\text{crit}} + \Delta\phi \\ \Delta\phi &= f(\sigma'_{\text{crit}}/\sigma') \end{aligned}$$

typical envelope fitting data:  
power curve  
 $(\tau/\tau_{\text{crit}}) = (\sigma'/\sigma'_{\text{crit}})^\alpha$   
with  $\alpha \approx 0.85$



Tangent angle of shearing envelope

$$\begin{aligned} \tau &= c' + \sigma' \tan \phi' \\ c' &= f(\sigma'_{\text{crit}}) \end{aligned}$$

typical envelope:  
straight line  
 $\tan \phi' = 0.85 \tan \phi_{\text{crit}}$   
 $c' = 0.15 \tau_{\text{crit}}$

● **Friction and dilation: data of sands**

The inter-granular friction angle of quartz grains,  $\phi_{\mu} \approx 26^{\circ}$ . Turbulent shearing at a critical state causes  $\phi_{\text{crit}}$  to exceed this. The critical state angle of internal friction  $\phi_{\text{crit}}$  is a function of the uniformity of particle sizes, their shape, and mineralogy, and is developed at large shear strains irrespective of initial conditions. Typical values of  $\phi_{\text{crit}} (\pm 2^{\circ})$  are:

well-graded, angular quartz or feldspar sands	40°
uniform sub-angular quartz sand	36°
uniform rounded quartz sand	32°

Relative density  $I_D = \frac{(e_{\text{max}} - e)}{(e_{\text{max}} - e_{\text{min}})}$  where:

$e_{\text{max}}$  is the maximum void ratio achievable in quick-tilt test

$e_{\text{min}}$  is the minimum void ratio achievable by vibratory compaction

Relative crushability  $I_C = \ln(\sigma_c / p')$  where:

$\sigma_c$  is the aggregate crushing stress, taken to be a material constant, typical values being: 80 000 kPa for quartz silt, 20 000 kPa for quartz sand, 5 000 kPa for carbonate sand.

$p'$  is the mean effective stress at failure which may be taken as approximately equal to the effective stress  $\sigma'$  normal to a shear plane.

Dilatancy contribution to the peak angle of internal friction is  $\Delta\phi = (\phi_{\text{max}} - \phi_{\text{crit}}) = f(I_R)$

Relative dilatancy index  $I_R = I_D I_C - 1$  where:


$I_R < 0$  indicates compaction, so that  $I_D$  increases and  $I_R \rightarrow 0$  ultimately at a critical state

$I_R > 4$  to be limited to  $I_R = 4$  unless corroborative dilatant strength data is available

The following empirical correlations are then available


plane strain conditions	$(\phi_{\text{max}} - \phi_{\text{crit}})$	$= 0.8 \psi_{\text{max}}$	$= 5 I_R$ degrees
triaxial strain conditions	$(\phi_{\text{max}} - \phi_{\text{crit}})$	$= 3 I_R$ degrees	
all conditions	$(-\delta\varepsilon_v / \delta\varepsilon_1)_{\text{max}}$	$= 0.3 I_R$	

The resulting peak strength envelope for triaxial tests on a quartz sand at an initial relative density  $I_D = 1$  is shown below for the limited stress range 10 - 400 kPa:



$$\phi_{\text{max}} > \phi_{\text{crit}} + 9^{\circ} \quad \text{for } I_D = 1, \sigma' = 400 \text{ kPa}$$

• Mobilised (secant) angle of shearing  $\phi$  in the 1 – 3 plane




$$\begin{aligned} \sin \phi &= TS/OS \\ &= \frac{(\sigma'_1 - \sigma'_3)/2}{(\sigma'_1 + \sigma'_3)/2} \\ \left[ \frac{\sigma'_1}{\sigma'_3} \right] &= \frac{(1 + \sin \phi)}{(1 - \sin \phi)} \end{aligned}$$

Angle of shearing resistance:

at peak strength  $\phi_{\max}$  at  $\left[ \frac{\sigma'_1}{\sigma'_3} \right]_{\max}$

at critical state  $\phi_{\text{crit}}$  after large shear strains

• Mobilised angle of dilation in plane strain  $\psi$  in the 1 – 3 plane



$$\begin{aligned} \sin \psi &= VO/VZ \\ &= -\frac{(\delta \epsilon_1 + \delta \epsilon_3)/2}{(\delta \epsilon_1 - \delta \epsilon_3)/2} \\ &= -\frac{\delta \epsilon_v}{\delta \epsilon_\gamma} \\ \left[ \frac{\delta \epsilon_1}{\delta \epsilon_3} \right] &= -\frac{(1 - \sin \psi)}{(1 + \sin \psi)} \end{aligned}$$

at peak strength  $\psi = \psi_{\max}$  at  $\left[ \frac{\sigma'_1}{\sigma'_3} \right]_{\max}$

at critical state  $\psi = 0$  since volume is constant

**Plasticity: Cohesive material  $\tau_{max} = c_u$  (or  $s_u$ )**

• **Limiting stresses**

Tresca  $|\sigma_1 - \sigma_3| = q_u = 2c_u$

von Mises  $(\sigma_1 - p)^2 + (\sigma_2 - p)^2 + (\sigma_3 - p)^2 = \frac{2}{3} q_u^2 = 2c_u^2$

where  $q_u$  is the undrained triaxial compression strength, and  $c_u$  is the undrained plane shear strength.


Dissipation per unit volume in plane strain deformation following either Tresca or von Mises,

$$\delta D = c_u \delta \epsilon_\gamma$$

For a relative displacement  $x$  across a slip surface of area  $A$  mobilising shear strength  $c_u$ , this becomes

$$D = Ac_u x$$

• **Stress conditions across a discontinuity**




Rotation of major principal stress  $\theta$

$$s_B - s_A = \Delta s = 2c_u \sin \theta$$

$$\sigma_{1B} - \sigma_{1A} = 2c_u \sin \theta$$

In limit with  $\theta \rightarrow 0$

$$ds = 2c_u d\theta$$



Useful example:

$$\theta = 30^\circ$$

$$\sigma_{1B} - \sigma_{1A} = c_u$$

$$\tau_D / c_u = 0.87$$

$\sigma_{1A}$  = major principal stress in zone A

$\sigma_{1B}$  = major principal stress in zone B

**Plasticity: Frictional material**  $(\tau/\sigma')_{\max} = \tan \phi$

• **Limiting stresses**

$$\sin \phi = (\sigma'_{1f} - \sigma'_{3f}) / (\sigma'_{1f} + \sigma'_{3f}) = (\sigma_{1f} - \sigma_{3f}) / (\sigma_{1f} + \sigma_{3f} - 2u_s)$$

where  $\sigma'_{1f}$  and  $\sigma'_{3f}$  are the major and minor principal effective stresses at failure,  $\sigma_{1f}$  and  $\sigma_{3f}$  are the major and minor principle total stresses at failure, and  $u_s$  is the steady state pore pressure.

Active pressure:

$$\sigma'_v > \sigma'_h$$

$$\sigma'_1 = \sigma'_v \text{ (assuming principal stresses are horizontal and vertical)}$$

$$\sigma'_3 = \sigma'_h$$

$$K_a = (1 - \sin \phi) / (1 + \sin \phi)$$

Passive pressure:



$$\sigma'_h > \sigma'_v$$

$$\sigma'_1 = \sigma'_h \text{ (assuming principal stresses are horizontal and vertical)}$$

$$\sigma'_3 = \sigma'_v$$

$$K_p = (1 + \sin \phi) / (1 - \sin \phi) = 1 / K_a$$

• **Stress conditions across a discontinuity**



$$\sin \Omega = \sin \delta / \sin \phi$$

$$s'_B / s'_A = \sin(\Omega + \delta) / \sin(\Omega - \delta)$$

In limit,  $d\theta \rightarrow 0$  and  $\delta \rightarrow \phi$

$$ds' = 2s' \cdot d\theta \tan \phi$$

Integration gives  $s'_B / s'_A = \exp(2\theta \tan \phi)$

## Empirical earth pressure coefficients following one-dimensional strain

Coefficient of earth pressure in 1D plastic compression (normal compression)

$$K_{o,nc} = 1 - \sin \phi_{crit}$$

Coefficient of earth pressure during a 1D unloading-reloading cycle (overconsolidated soil)

$$K_o = K_{o,nc} \left[ 1 + \frac{(n-1)(n_{max}^\alpha - 1)}{(n_{max} - 1)} \right]$$

where  $n$  is current overconsolidation ratio (OCR) defined as  $\sigma'_{v,max} / \sigma'_v$

$n_{max}$  is maximum historic OCR defined as  $\sigma'_{v,max} / \sigma'_{v,min}$

$\alpha$  is to be taken as  $1.2 \sin \phi_{crit}$

## Cylindrical cavity expansion

Expansion  $\delta A = A - A_o$  caused by increase of pressure  $\delta \sigma_c = \sigma_c - \sigma_o$

At radius  $r$ : small displacement  $\rho = \frac{\delta A}{2\pi r}$


small shear strain  $\gamma = \frac{2\rho}{r}$

Radial equilibrium:  $r \frac{d\sigma_r}{dr} + \sigma_r - \sigma_\theta = 0$

Elastic expansion (small strains)  $\delta \sigma_c = G \frac{\delta A}{A}$

Undrained plastic-elastic expansion  $\delta \sigma_c = c_u \left[ 1 + \ln \frac{G}{c_u} + \ln \frac{\delta A}{A} \right]$

## Infinite slope analysis



$$\begin{aligned} u &= \gamma_w z_w \cos^2 \beta \\ \sigma &= \gamma z \cos^2 \beta \\ \sigma' &= (\gamma z - \gamma_w z_w) \cos^2 \beta \\ \tau &= \gamma z \cos \beta \sin \beta \end{aligned}$$

$$\tan \phi_{mob} = \frac{\tau}{\sigma'} = \frac{\tan \beta}{\left(1 - \frac{\gamma_w z_w}{\gamma z}\right)}$$

## Shallow foundation design

### *Tresca soil, with undrained strength $s_u$*

#### Vertical loading

The vertical bearing capacity,  $q_f$ , of a shallow foundation for undrained loading (Tresca soil) is:

$$\frac{V_{ult}}{A} = q_f = s_c d_c N_c s_u + \gamma h$$

$V_{ult}$  and  $A$  are the ultimate vertical load and the foundation area, respectively.  $h$  is the embedment of the foundation base and  $\gamma$  (or  $\gamma'$ ) is the appropriate density of the overburden.

The exact bearing capacity factor  $N_c$  for a plane strain surface foundation (zero embedment) on uniform soil is:

$$N_c = 2 + \pi \quad (\text{Prandtl, 1921})$$

#### *Shape correction factor:*

For a rectangular footing of length  $L$  and breadth  $B$  (Eurocode 7):

$$s_c = 1 + 0.2 B / L$$

The exact solution for a rough circular foundation ( $D = B = L$ ) is  $q_f = 6.05s_u$ , hence  $s_c = 1.18 \sim 1.2$ .

#### *Embedment correction factor:*

A fit to Skempton's (1951) embedment correction factors, for an embedment of  $h$ , is:

$$d_c = 1 + 0.33 \tan^{-1} (h/B) \quad (\text{or } h/D \text{ for a circular foundation})$$

#### Combined V-H loading

A curve fit to Green's lower bound plasticity solution for V-H loading is:

$$\text{If } V/V_{ult} > 0.5: \quad \frac{V}{V_{ult}} = \frac{1}{2} + \frac{1}{2} \sqrt{1 - \frac{H}{H_{ult}}} \quad \text{or} \quad \frac{H}{H_{ult}} = 1 - \left( 2 \frac{V}{V_{ult}} - 1 \right)^2$$

$$\text{If } V/V_{ult} < 0.5: \quad H = H_{ult} = Bs_u$$

#### Combined V-H-M loading

With lift-off: combined Green-Meyerhof

$$\text{Without lift-off: } \left( \frac{V}{V_{ult}} \right)^2 + \left[ \frac{M}{M_{ult}} \left( 1 - 0.3 \frac{H}{H_{ult}} \right) \right]^2 + \left| \left( \frac{H}{H_{ult}} \right)^3 \right| - 1 = 0 \quad (\text{Taiebet \& Carter 2000})$$



## Frictional (Coulomb) soil, with friction angle $\phi$

### Vertical loading

The vertical bearing capacity,  $q_f$ , of a shallow foundation under drained loading (Coulomb soil) is:

$$\frac{V_{ult}}{A} = q_f = s_q N_q \sigma'_{v0} + s_\gamma N_\gamma \frac{\gamma' B}{2}$$

The bearing capacity factors  $N_q$  and  $N_\gamma$  account for the capacity arising from surcharge and self-weight of the foundation soil respectively.  $\sigma'_{v0}$  is the in situ effective stress acting at the level of the foundation base.

For a strip footing on weightless soil, the exact solution for  $N_q$  is:

$$N_q = \tan^2(\pi/4 + \phi/2) e^{(\pi \tan \phi)} \quad (\text{Prandtl 1921})$$

An empirical relationship to estimate  $N_\gamma$  from  $N_q$  is (Eurocode 7):

$$N_\gamma = 2(N_q - 1) \tan \phi$$

Curve fits to exact solutions for  $N_\gamma = f(\phi)$  are (Davis & Booker 1971):

$$\text{Rough base: } N_\gamma = 0.1054 e^{9.6\phi}$$

$$\text{Smooth base: } N_\gamma = 0.0663 e^{9.3\phi}$$

### Shape correction factors:

For a rectangular footing of length  $L$  and breadth  $B$  (Eurocode 7):

$$s_q = 1 + (B \sin \phi) / L$$

$$s_\gamma = 1 - 0.3 B / L$$

For circular footings take  $L = B$ .

### Combined V-H loading

The Green/Sokolovski lower bound solution gives a V-H failure surface.


### Combined V-H-M loading

With lift-off- drained conditions - use Butterfield & Gottardi (1994) failure surface shown above

$$\left[ \frac{H/V_{ult}}{t_h} \right]^2 + \left[ \frac{M/BV_{ult}}{t_m} \right]^2 + \left[ \frac{2C(M/BV_{ult})(H/V_{ult})}{t_h t_m} \right] = \left[ \frac{V}{V_{ult}} \left( 1 - \frac{V}{V_{ult}} \right) \right]^2$$

$$\text{where } C = \tan \left( \frac{2\rho(t_h - t_m)(t_h + t_m)}{2t_h t_m} \right) \quad (\text{Butterfield \& Gottardi, 1994})$$

Typically,  $t_h \sim 0.5$ ,  $t_m \sim 0.4$  and  $\rho \sim 15^\circ$ . Note that  $t_h$  is the friction coefficient,  $H/V = \tan \phi$ , during sliding.



## Settlement of Shallow Foundations

### Elastic stress distributions below point, strip and circular loads


#### Point loading (Boussinesq solution)

Vertical stress  $\sigma_z = \frac{3Pz^3}{2\pi R^5}$

Radial stress  $\sigma_r = \frac{P}{2\pi R^2} \left[ \frac{3r^2z}{R^3} - \frac{(1-2\nu)R}{R+z} \right]$

Tangential stress  $\sigma_\theta = \frac{P(1-2\nu)}{2\pi R^2} \left[ \frac{R}{R+z} - \frac{z}{R} \right]$

Shear stress  $\tau_{rz} = \frac{3Prz^2}{2\pi R^5}$




#### Uniformly-loaded strip

Vertical stress  $\sigma_v = \frac{q}{\pi} [\alpha + \sin \alpha \cos(\alpha + 2\delta)]$

Horizontal stress  $\sigma_h = \frac{q}{\pi} [\alpha - \sin \alpha \cos(\alpha + 2\delta)]$

Shear stress  $\tau_{vh} = \frac{q}{\pi} \sin \alpha \sin(\alpha + 2\delta)$


Principal stresses  $\sigma_1 = \frac{q}{\pi} (\alpha + \sin \alpha) \quad \sigma_3 = \frac{q}{\pi} (\alpha - \sin \alpha)$



#### Uniformly-loaded circle radius a (on centerline, r=0)

Vertical stress  $\sigma_v = q \left[ 1 - \left( \frac{1}{1 + (a/z)^2} \right)^{\frac{3}{2}} \right]$

Horizontal stress  $\sigma_h = \frac{q}{2} \left[ (1 + 2\nu) - \frac{2(1 + \nu)z}{(a^2 + z^2)^{1/2}} + \frac{z^3}{(a^2 + z^2)^{3/2}} \right]$



Contours of vertical stress below uniformly-loaded circular (left) and strip foundations (right)

**Elastic solutions for surface settlement**  
**Isotropic, homogeneous, elastic half-space (semi-infinite)**

**Point load (Boussinesq solution)**

Settlement,  $w$ , at distance  $s$ : 
$$w(s) = \frac{1}{2\pi} \frac{(1-\nu) P}{G s}$$

**Circular area (radius  $a$ ), uniform soil**

Uniform load:                    central settlement:       $w_o = \frac{(1-\nu)}{G} qa$   
    edge settlement:             $w_e = \frac{2(1-\nu)}{\pi G} qa$   
 Rigid punch: ( $q_{avg} = V/\pi a^2$ )       $w_r = \frac{\pi(1-\nu)}{4 G} q_{avg} a$

**Rectangular area, uniform soil**

Uniform load, corner settlement:

$$w_c = \frac{(1-\nu) qB}{G} \frac{1}{2} I_{rect}$$

Where  $I_{rect}$  depends on the aspect ratio,  $L/B$ :

L/B	$I_{rect}$	L/B	$I_{rect}$	L/B	$I_{rect}$	L/B	$I_{rect}$
1	0.561	1.6	0.698	2.4	0.822	5	1.052
1.1	0.588	1.7	0.716	2.5	0.835	6	1.110
1.2	0.613	1.8	0.734	3	0.892	7	1.159
1.3	0.636	1.9	0.750	3.5	0.940	8	1.201
1.4	0.658	2	0.766	4	0.982	9	1.239
1.5	0.679	2.2	0.795	4.5	1.019	10	1.272

Rigid rectangle:  $w_r = \frac{(1-\nu) q_{avg} \sqrt{BL}}{G} I_{rgd}$  where  $I_{rgd}$  varies from 0.9→0.7 for  $L/B = 1-10$ .

Note:  $G = \frac{E}{2(1+\nu)}$  where  $\nu$ = Poisson's ratio,  $E$ = Young's modulus.