

ENGINEERING TRIPOS PART IIA

---

Friday 6 May 2011

2.30 to 4

---

Module 3D2

GEOTECHNICAL ENGINEERING II

*Answer not more than **three** questions.*

*All questions carry the same number of marks.*

*The **approximate** percentage of marks allocated to each part of a question is indicated in the right margin.*

*Attachment: Geotechnical Engineering Data Book (19 pages)*

STATIONERY REQUIREMENTS

Single-sided script paper

Graph paper

SPECIAL REQUIREMENTS

Engineering Data Book

CUED approved calculator allowed

**You may not start to read the questions  
printed on the subsequent pages of this  
question paper until instructed that you  
may do so by the Invigilator**

1 (a) Sketch a schematic diagram of peak strength envelopes of loose and dense sands in  $\sigma' - \tau$  space and comment on the shape in relation to the conventional Mohr-Coulomb failure envelope using  $c'$  and  $\phi'$ . Discuss any consideration needed when the conventional failure envelope is used to characterise the peak strength of sands. [15%]

(b) Discuss why progressive failure is likely to happen in dense soil and why the critical state strengths are preferred for such soil in geotechnical design. [15%]

(c) The soil taken from a field site is found to be uniform sub-angular quartz sand, which has maximum and minimum void ratios of 0.90 and 0.40.

(i) Assuming that the critical state occurs when the relative dilatancy index  $I_R$  is zero, plot the critical state line in  $e - \ln \sigma_v'$  space. Try several vertical stresses (100, 200, 500, 1000, 2000 and 5000 kPa) to obtain the line. Comment on the shape of the line compared to the critical state line in clay. [20%]

(ii) In the graph drawn in (i), sketch schematically a possible normal compression line when a specimen of this sand is initially compacted at a void ratio of 0.7 and then consolidated. Comment on the general shear behaviour of the specimen in relation to the applied confining stress. [10%]

(iii) The in-situ void ratio is 0.65 at a depth where the vertical effective stress is 200 kPa. Estimate the peak drained shear strength and the critical state strength at this depth in simple shear under plane strain conditions. Evaluate the void ratio at the critical state. Sketch the shear stress – shear strain relationship and the volumetric strain – shear strain relationship, giving salient values. [20%]

(iv) The in-situ void ratio is 0.80 at a depth where the vertical effective stress is 150 kPa. Estimate the undrained shear strength at the critical state in simple shear under plane strain conditions. Evaluate the excess pore pressure generated at failure in undrained conditions. Sketch the shear stress – shear strain relationship and the excess pore pressure – shear strain relationship, giving salient values. [20%]

2 Triaxial compression tests are performed on reconstituted London clay samples. Use the material parameters of London clay given in the Data Book, and the Cam clay model when necessary, to answer the following questions.

(a) A reconstituted London clay specimen is isotropically consolidated to 100 kPa. The specimen is then subjected to drained shear tests. Estimate the drained strength and the volumetric strain generated at failure for the following tests. For each case, draw the stress path in  $p' - q$  space and the state path in  $v - \ln p'$  space.

(i) A triaxial compression test where the axial stress is increased and the radial stress is kept constant. [25%]

(ii) A triaxial extension test where the radial stress is increased and the axial stress is kept constant. [25%]

(b) A reconstituted London clay specimen is isotropically consolidated to 300 kPa, and then unloaded to 100 kPa during which swelling is allowed to complete. It is then subjected to undrained axial compression, in which the axial stress is increased and the radial stress is kept constant.

(i) Estimate the undrained shear strength and the excess pore pressure generated at failure. [20%]

(ii) Calculate the yield stress when it starts to exhibit plastic behaviour. [15%]

(iii) To what isotropic pressure does the clay need to be normally consolidated in order to give the same undrained shear strength calculated in (i)? [15%]

(TURN OVER

3 A 10 m diameter tunnel is to be constructed at a depth of 30 m in clay below a building on pile foundations, as shown in Fig. 1. For a previous tunnel of the same size and depth in clay with identical properties but not with building above, the measured settlement at the tunnel crown was 50 mm. The clay has an undrained shear strength  $c_u = 150 \text{ kNm}^{-2}$  and an elastic shear modulus  $G = 50 \text{ MNm}^{-2}$ . The unit weight of the clay is  $\gamma = 20 \text{ kNm}^{-3}$ . The influence of the piles and the building on the ground behaviour should be ignored.

Assume that the tunnel construction process can be considered to be an axisymmetric contracting cylindrical cavity under undrained conditions, supported by a smooth tunnel lining.

(a) Calculate the maximum settlement at the toe of the piles. [20%]

(b) The clay can be idealized as a linear elastic-perfectly plastic material. After yield has occurred, there is a plastic zone around the tunnel surrounded by an elastic zone. Within the elastic zone, at any radius  $r$ , the radial and circumferential stresses,  $\sigma_r$  and  $\sigma_\theta$  respectively, are given by the following expressions:

$$\sigma_r = \sigma_0 - G \delta A / \pi r^2$$

$$\sigma_\theta = \sigma_0 + G \delta A / \pi r^2$$

where  $\sigma_0$  is the original insitu total stress in the ground,  $G$  is the elastic shear modulus and  $\delta A$  is the reduction in cross-sectional area of the cavity. Show that the radius of the plastic zone,  $r_p$ , is given by the following expression:

$$\frac{r_p}{r_c} = \left( \frac{G}{c_u} \cdot \frac{\delta A}{A} \right)^{0.5}$$

where  $r_c$  is the radius of the cavity,  $A$  is the cross-sectional area of the cavity and the other symbols are as defined above. [30%]

(c) By how much will the pile immediately above the tunnel centre-line extend into the plastic zone? [25%]

(d) Assuming that the building load is negligible, calculate the average radial stress acting on the tunnel lining after excavation. [25%]

(cont.)




Fig. 1

(TURN OVER

4 Figure 2 shows a smooth retaining wall supporting a uniform clay, for which the critical state friction angle is  $\phi_{crit} = 25^\circ$  and the bulk unit weight is  $20 \text{ kNm}^{-3}$  both above and below the water table. A long time before the wall was installed the clay had been deposited one-dimensionally under normally consolidated conditions and the ground surface had been at a maximum of 20 m above the present ground level; the water level at that time had been at the ground surface. Since then 20 m of soil has been eroded, and the water level is now 1 m below the present ground level.

(a) Calculate the stresses experienced by the clay element A at a depth of 10 m below the present ground surface, as follows:

(i) Using the expression in the Data Book for the coefficient of earth pressure  $K_{0,nc}$ , calculate the original maximum total and effective vertical and horizontal stresses. [10%]

(ii) Calculate the present day overconsolidation ratio, and the total and effective vertical and horizontal stresses, assuming  $K_0 = 0.9$ , before the wall is installed. [15%]

(iii) Plot these stresses in terms of  $t$ ,  $s'$  and  $s$  (as defined in the Data Book), show the effective stress history in terms of stress paths, and also plot the critical state line. [15%]

(b) After the wall is installed, the soil in front of it is excavated rapidly under undrained conditions and replaced with struts incorporating jacks applying loads to the wall equivalent to a uniform soil pressure  $P = 120 \text{ kPa}$ . Assuming that the soil behaves elastically, calculate the change of pore pressure for the clay element A. Show the total and effective stress paths on your graph. [30%]

(c) Following completion of the excavation, the support pressure  $P$  is maintained at 120 kPa by adjusting the jacks in the struts but the pore pressure in the soil starts to increase with time. When the clay element at A reaches the critical state line, by how much would the pore pressure have increased? [30%]

(cont.)




Fig. 2


**END OF PAPER**

**Engineering Tripos Part IIA****3D1 & 3D2  
Geotechnical Engineering****Data Book 2010-2011**

<b>Contents</b>	<b>Page</b>
General definitions	2
Soil classification	3
Seepage	4
One-dimensional compression	5
One-dimensional consolidation	6
Stress and strain components	7, 8
Elastic stiffness relations	9
Cam Clay	10, 11
Friction and dilation	12, 13, 14
Plasticity; cohesive material	15
Plasticity; frictional material	16
Empirical earth pressure coefficients	17
Cylindrical cavity expansion	17
Infinite slope analysis	17
Shallow foundation capacity	18, 19



**General definitions**



Specific gravity of solid

$$G_s$$

Voids ratio

$$e = V_v / V_s$$

Specific volume

$$v = V_t / V_s = 1 + e$$

Porosity

$$n = V_v / V_t = e / (1 + e)$$

Water content

$$w = (W_w / W_s)$$

Degree of saturation

$$S_r = V_w / V_v = (w G_s / e)$$

Unit weight of water

$$\gamma_w = 9.81 \text{ kN/m}^3$$

Unit weight of soil

$$\gamma = W_t / V_t = \left( \frac{G_s + S_r e}{1 + e} \right) \gamma_w$$

Buoyant saturated unit weight

$$\gamma' = \gamma - \gamma_w = \left( \frac{G_s - 1}{1 + e} \right) \gamma_w$$

Unit weight of dry solids

$$\gamma_d = W_s / V_t = \left( \frac{G_s}{1 + e} \right) \gamma_w$$

Air volume ratio

$$A = V_a / V_t = \left( \frac{e(1 - S_r)}{1 + e} \right)$$

**Soil classification (BS1377)**Liquid limit  $w_L$ Plastic Limit  $w_p$ Plasticity Index  $I_p = w_L - w_p$ Liquidity Index  $I_L = \frac{w - w_p}{w_L - w_p}$ Activity =  $\frac{\text{Plasticity Index}}{\text{Percentage of particles finer than } 2 \mu\text{m}}$ Sensitivity =  $\frac{\text{Unconfined compressive strength of an undisturbed specimen}}{\text{Unconfined compressive strength of a remoulded specimen}}$  (at the same water content)*Classification of particle sizes:-*


Boulders	larger than			200 mm
Cobbles	between	200 mm	and	60 mm
Gravel	between	60 mm	and	2 mm
Sand	between	2 mm	and	0.06 mm
Silt	between	0.06 mm	and	0.002 mm
Clay	smaller than	0.002 mm (two microns)		

D equivalent diameter of soil particle

 $D_{10}$ ,  $D_{60}$  etc. particle size such that 10% (or 60%) etc.) by weight of a soil sample is composed of finer grains. $C_u$  uniformity coefficient  $D_{60} / D_{10}$

## Seepage

Flow potential:  
(piezometric level)



Total gauge pore water pressure at A:  $u = \gamma_w h = \gamma_w (\bar{h} + z)$

$$B: u + \Delta u = \gamma_w (h + \Delta h) = \gamma_w (\bar{h} + z + \Delta \bar{h} + \Delta z)$$

Excess pore water pressure at A:  $\bar{u} = \gamma_w \bar{h}$

$$B: \bar{u} + \Delta \bar{u} = \gamma_w (\bar{h} + \Delta \bar{h})$$

Hydraulic gradient A  $\rightarrow$  B  $i = - \frac{\Delta \bar{h}}{\Delta s}$

Hydraulic gradient (3D)  $i = - \nabla \bar{h}$

Darcy's law  $V = ki$

$V$  = superficial seepage velocity

$k$  = coefficient of permeability

Typical permeabilities:

$D_{10} > 10 \text{ mm}$	: non-laminar flow
$10 \text{ mm} > D_{10} > 1 \mu\text{m}$	: $k \cong 0.01 (D_{10} \text{ in mm})^2 \text{ m/s}$
clays	: $k \cong 10^{-9} \text{ to } 10^{-11} \text{ m/s}$


Saturated capillary zone

$$h_c = \frac{4T}{\gamma_w d} \quad : \text{ capillary rise in tube diameter } d, \text{ for surface tension } T$$

$$h_c \approx \frac{3 \times 10^{-5}}{D_{10}} \text{ m} \quad : \text{ for water at } 10^\circ\text{C}; \text{ note air entry suction is } u_c = -\gamma_w h_c$$

## One-Dimensional Compression

### • Fitting data



Plastic compression stress  $\sigma'_c$  is taken as the larger of the initial aggregate crushing stress and the historic maximum effective vertical stress. Clay muds are taken to begin with  $\sigma'_c \approx 1$  kPa.

Plastic compression (normal compression line, ncl):  $v = v_\lambda - \lambda \ln \sigma'$  for  $\sigma' = \sigma'_c$

Elastic swelling and recompression line (esrl):  
 $v = v_c + \kappa (\ln \sigma'_c - \ln \sigma'_v)$   
 $= v_\kappa - \kappa \ln \sigma'_v$  for  $\sigma' < \sigma'_c$

Equivalent parameters for  $\log_{10}$  stress scale:

Terzaghi's compression index  $C_c = \lambda \log_{10} e$

Terzaghi's swelling index  $C_s = \kappa \log_{10} e$

### • Deriving confined soil stiffnesses

Secant 1D compression modulus  $E_o = (\Delta \sigma' / \Delta \epsilon)_o$


Tangent 1D plastic compression modulus  $E_o = v \sigma' / \lambda$

Tangent 1D elastic compression modulus  $E_o = v \sigma' / \kappa$

### One-Dimensional Consolidation

Settlement	$\rho$	$= \int m_v (\Delta u - \bar{u}) dz$	$= \int (\Delta u - \bar{u}) / E_o dz$
Coefficient of consolidation	$c_v$	$= \frac{k}{m_v \gamma_w}$	$= \frac{kE_o}{\gamma_w}$
Dimensionless time factor	$T_v$	$= \frac{c_v t}{d^2}$	
Relative settlement	$R_v$	$= \frac{\rho}{\rho_{ult}}$	

• Solutions for initially rectangular distribution of excess pore pressure



Approximate solution by parabolic isochrones:

Phase (i)  $L^2 = 12 c_v t$   
 $R_v = \sqrt{\frac{4T_v}{3}}$  for  $T_v < 1/12$

Phase (ii)  $b = \exp(1/4 - 3T_v)$   
 $R_v = [1 - 2/3 \exp(1/4 - 3T_v)]$  for  $T_v > 1/12$

Solution by Fourier Series:

$T_v$	0	0.01	0.02	0.04	0.08	0.15	0.20	0.30	0.40	0.50	0.60	0.80	1.00
$R_v$	0	0.12	0.17	0.23	0.32	0.45	0.51	0.62	0.70	0.77	0.82	0.89	0.94

## Stress and strain components

### • Principle of effective stress (saturated soil)

$$\text{total stress } \sigma = \text{effective stress } \sigma' + \text{pore water pressure } u$$

### • Principal components of stress and strain

sign convention	compression positive
total stress	$\sigma_1, \sigma_2, \sigma_3$
effective stress	$\sigma'_1, \sigma'_2, \sigma'_3$
strain	$\varepsilon_1, \varepsilon_2, \varepsilon_3$

### • Simple Shear Apparatus (SSA) ( $\varepsilon_2 = 0$ ; other principal directions unknown)

The only stresses that are readily available are the shear stress  $\tau$  and normal stress  $\sigma$  applied to the top platen. The pore pressure  $u$  can be controlled and measured, so the normal effective stress  $\sigma'$  can be found. Drainage can be permitted or prevented. The shear strain  $\gamma$  and normal strain  $\varepsilon$  are measured with respect to the top platen, which is a plane of zero extension. Zero extension planes are often identified with slip surfaces.

$$\text{work increment per unit volume} \quad \delta W = \tau \delta\gamma + \sigma' \delta\varepsilon$$

### • Biaxial Apparatus - Plane Strain (BA-PS) ( $\varepsilon_2 = 0$ ; rectangular edges along principal axes)

Intermediate principal effective stress  $\sigma'_2$ , in zero strain direction, is frequently unknown so that all conditions are related to components in the 1-3 plane.

mean total stress	$s = (\sigma_1 + \sigma_3)/2$
mean effective stress	$s' = (\sigma'_1 + \sigma'_3)/2 = s - u$
shear stress	$t = (\sigma'_1 - \sigma'_3)/2 = (\sigma_1 - \sigma_3)/2$

$$\text{volumetric strain} \quad \varepsilon_v = \varepsilon_1 + \varepsilon_3$$

$$\text{shear strain} \quad \varepsilon_\gamma = \varepsilon_1 - \varepsilon_3$$

$$\text{work increment per unit volume} \quad \delta W = \sigma'_1 \delta\varepsilon_1 + \sigma'_3 \delta\varepsilon_3$$

$$\delta W = s' \delta\varepsilon_v + t \delta\varepsilon_\gamma$$

providing that principal axes of strain increment and of stress coincide.

• **Triaxial Apparatus – Axial Symmetry (TA-AS)** (cylindrical element with radial symmetry)


total axial stress	$\sigma_a = \sigma'_a + u$
total radial stress	$\sigma_r = \sigma'_r + u$
total mean normal stress	$p = (\sigma_a + 2\sigma_r)/3$
effective mean normal stress	$p' = (\sigma'_a + 2\sigma'_r)/3 = p - u$
deviatoric stress	$q = \sigma'_a - \sigma'_r = \sigma_a - \sigma_r$
stress ratio	$\eta = q/p'$
axial strain	$\epsilon_a$
radial strain	$\epsilon_r$
volumetric strain	$\epsilon_v = \epsilon_a + 2\epsilon_r$
triaxial shear strain	$\epsilon_s = \frac{2}{3}(\epsilon_a - \epsilon_r)$
work increment per unit volume	$\delta W = \sigma'_a \delta \epsilon_a + 2\sigma'_r \delta \epsilon_r$
	$\delta W = p' \delta \epsilon_v + q \delta \epsilon_s$

Types of triaxial test include:

- isotropic compression* in which  $p'$  increases at zero  $q$
- triaxial compression* in which  $q$  increases *either* by increasing  $\sigma_a$  *or* by reducing  $\sigma_r$
- triaxial extension* in which  $q$  reduces *either* by reducing  $\sigma_a$  *or* by increasing  $\sigma_r$

• **Mohr's circle of stress (1–3 plane)**

Sign of convention: compression, and counter-clockwise shear, positive



*Poles of planes P*: the components of stress on the N plane are given by the intersection N of the Mohr circle with the line PN through P parallel to the plane.

## Elastic stiffness relations

These relations apply to tangent stiffnesses of over-consolidated soil, with a state point on some swelling and recompression line ( $\kappa$ -line), and remote from gross plastic yielding.

One-dimensional compression (axial stress and strain increments  $d\sigma'$ ,  $d\varepsilon$ )

$$\text{compressibility} \quad m_v = \frac{d\varepsilon}{d\sigma'}$$

$$\text{constrained modulus} \quad E_o = \frac{1}{m_v}$$

Physically fundamental parameters

$$\text{shear modulus} \quad G' = \frac{dt}{d\varepsilon_\gamma}$$

$$\text{bulk modulus} \quad K' = \frac{dp'}{d\varepsilon_v}$$

Parameters which can be used for constant-volume deformations

$$\text{undrained shear modulus} \quad G_u = G'$$

$$\text{undrained bulk modulus} \quad K_u = \infty \quad (\text{neglecting compressibility of water})$$

Alternative convenient parameters

$$\text{Young's moduli} \quad E' \text{ (effective), } E_u \text{ (undrained)}$$

$$\text{Poisson's ratios} \quad \nu' \text{ (effective), } \nu_u = 0.5 \text{ (undrained)}$$

Typical value of Poisson's ratio for small changes of stress:  $\nu' = 0.2$

$$\text{Relationships: } G = \frac{E}{2(1+\nu)}$$

$$K = \frac{E}{3(1-2\nu)}$$

$$E_o = \frac{E(1-\nu)}{(1+\nu)(1-2\nu)}$$



## Cam Clay

### • Interchangeable parameters for stress combinations at yield, and plastic strain increments

System	Effective normal stress	Plastic normal strain	Effective shear stress	Plastic shear strain	Critical stress ratio	Plastic normal stress	Critical normal stress
General	$\sigma^*$	$\varepsilon^*$	$\tau^*$	$\gamma^*$	$\mu^*_{crit}$	$\sigma^*_c$	$\sigma^*_{crit}$
SSA	$\sigma'$	$\varepsilon$	$\tau$	$\gamma$	$\tan \phi_{crit}$	$\sigma'_c$	$\sigma'_{crit}$
BA-PS	$s'$	$\varepsilon_v$	$t$	$\varepsilon_\gamma$	$\sin \phi_{crit}$	$s'_c$	$s'_{crit}$
TA-AS	$p'$	$\varepsilon_v$	$q$	$\varepsilon_s$	$M$	$p'_c$	$p'_{crit}$

### • General equations of plastic work

Plastic work and dissipation

$$\sigma^* \delta\varepsilon^* + \tau^* \delta\gamma^* = \mu^*_{crit} \sigma^* \delta\gamma^*$$

Plastic flow rule – normality

$$\frac{d\tau^*}{d\sigma^*} \cdot \frac{d\gamma^*}{d\varepsilon^*} = -1$$

### • General yield surface


$$\frac{\tau^*}{\sigma^*} = \mu^* = \mu^*_{crit} \cdot \ln \left[ \frac{\sigma_c^*}{\sigma^*} \right]$$

### • Parameter values which fit soil data

	London Clay	Weald Clay	Kaolin	Dog's Bay Sand	Ham River Sand
$\lambda^*$	0.161	0.093	0.26	0.334	0.163
$\kappa^*$	0.062	0.035	0.05	0.009	0.015
$\Gamma^*$ at 1 kPa	2.759	2.060	3.767	4.360	3.026
$\sigma^*_{c, virgin}$ kPa	1	1	1	Loose 500 Dense 1500	Loose 2500 Dense 15000
$\phi_{crit}$	23°	24°	26°	39°	32°
$M_{comp}$	0.89	0.95	1.02	1.60	1.29
$M_{extrn}$	0.69	0.72	0.76	1.04	0.90
$w_L$	0.78	0.43	0.74	-----	-----
$w_p$	0.26	0.18	0.42	-----	-----
$G_s$	2.75	2.75	2.61	2.75	2.65

- Note: 1) parameters  $\lambda^*$ ,  $\kappa^*$ ,  $\Gamma^*$ ,  $\sigma^*_{c, virgin}$  should depend to a small extent on the deformation mode, e.g. SSA, BA-PS, TA-AS, etc. This may be neglected unless further information is given.  
 2) Sand which is loose, or loaded cyclically, compacts more than Cam Clay allows.



• The yield surface in  $(\sigma^*, \tau^*, v)$  space



ncl: normal compression line  
 $v = N - \lambda \ln \sigma^*$


csl: critical state line  
 $v = \Gamma - \lambda \ln \sigma^*$

where  $N = \Gamma + \lambda - \kappa$



• Regions of limiting soil behaviour

Variation of Cam Clay yield surface




Zone D: denser than critical, "dry",  
 dilation or negative excess pore pressures,  
 Hvorslev strength envelope,  
 friction-dilatancy theory,  
 unstable shear rupture, progressive failure

Zone L: looser than critical, "wet",  
 compaction or positive excess pore pressures,  
 Modified Cam Clay yield surface,  
 stable strain-hardening continuum

tension failure  
 $\sigma'_3 = 0$

## Strength of soil: friction and dilation

### • Friction and dilatancy: the saw-blade model of direct shear




Intergranular angle of friction at sliding contacts  $\phi_\mu$

Angle of dilation  $\psi_{max}$

Angle of internal friction  $\phi_{max} = \phi_\mu + \psi_{max}$


### • Friction and dilatancy: secant and tangent strength parameters



Secant angle of internal friction

$$\begin{aligned}\tau &= \sigma' \tan \phi_{max} \\ \phi_{max} &= \phi_{crit} + \Delta\phi \\ \Delta\phi &= f(\sigma'_{crit}/\sigma')\end{aligned}$$

typical envelope fitting data:  
power curve  
 $(\tau/\tau_{crit}) = (\sigma'/\sigma'_{crit})^\alpha$   
with  $\alpha \approx 0.85$



Tangent angle of shearing envelope

$$\begin{aligned}\tau &= c' + \sigma' \tan \phi' \\ c' &= f(\sigma'_{crit})\end{aligned}$$

typical envelope:  
straight line  
 $\tan \phi' = 0.85 \tan \phi_{crit}$   
 $c' = 0.15 \tau_{crit}$

• **Friction and dilation: data of sands**

The inter-granular friction angle of quartz grains,  $\phi_{\mu} \approx 26^{\circ}$ . Turbulent shearing at a critical state causes  $\phi_{\text{crit}}$  to exceed this. The critical state angle of internal friction  $\phi_{\text{crit}}$  is a function of the uniformity of particle sizes, their shape, and mineralogy, and is developed at large shear strains irrespective of initial conditions. Typical values of  $\phi_{\text{crit}} (\pm 2^{\circ})$  are:

well-graded, angular quartz or feldspar sands	40°
uniform sub-angular quartz sand	36°
uniform rounded quartz sand	32°

Relative density  $I_D = \frac{(e_{\text{max}} - e)}{(e_{\text{max}} - e_{\text{min}})}$  where:

$e_{\text{max}}$  is the maximum void ratio achievable in quick-tilt test

$e_{\text{min}}$  is the minimum void ratio achievable by vibratory compaction

Relative crushability  $I_C = \ln(\sigma_c / p')$  where:

$\sigma_c$  is the aggregate crushing stress, taken to be a material constant, typical values being: 80 000 kPa for quartz silt, 20 000 kPa for quartz sand, 5 000 kPa for carbonate sand.

$p'$  is the mean effective stress at failure which may be taken as approximately equal to the effective stress  $\sigma'$  normal to a shear plane.

Dilatancy contribution to the peak angle of internal friction is  $\Delta\phi = (\phi_{\text{max}} - \phi_{\text{crit}}) = f(I_R)$

Relative dilatancy index  $I_R = I_D I_C - 1$  where:


$I_R < 0$  indicates compaction, so that  $I_D$  increases and  $I_R \rightarrow 0$  ultimately at a critical state

$I_R > 4$  to be limited to  $I_R = 4$  unless corroborative dilatant strength data is available

The following empirical correlations are then available


plane strain conditions	$(\phi_{\text{max}} - \phi_{\text{crit}})$	= 0.8 $\psi_{\text{max}}$	= 5 $I_R$ degrees
triaxial strain conditions	$(\phi_{\text{max}} - \phi_{\text{crit}})$	= 3 $I_R$ degrees	
all conditions	$(-\delta\varepsilon_v / \delta\varepsilon_1)_{\text{max}}$	= 0.3 $I_R$	

The resulting peak strength envelope for triaxial tests on a quartz sand at an initial relative density  $I_D = 1$  is shown below for the limited stress range 10 - 400 kPa:



$$\phi_{\text{max}} > \phi_{\text{crit}} + 9^{\circ} \quad \text{for } I_D = 1, \sigma' = 400 \text{ kPa}$$

• Mobilised (secant) angle of shearing  $\phi$  in the 1 – 3 plane




$$\begin{aligned} \sin \phi &= TS/OS \\ &= \frac{(\sigma_1' - \sigma_3')/2}{(\sigma_1' + \sigma_3')/2} \\ \left[ \frac{\sigma_1'}{\sigma_3'} \right] &= \frac{(1 + \sin \phi)}{(1 - \sin \phi)} \end{aligned}$$

Angle of shearing resistance:

at peak strength  $\phi_{\max}$  at  $\left[ \frac{\sigma_1'}{\sigma_3'} \right]_{\max}$

at critical state  $\phi_{\text{crit}}$  after large shear strains

• Mobilised angle of dilation in plane strain  $\psi$  in the 1 – 3 plane



$$\begin{aligned} \sin \psi &= VO/VZ \\ &= -\frac{(\delta\epsilon_1 + \delta\epsilon_3)/2}{(\delta\epsilon_1 - \delta\epsilon_3)/2} \\ &= -\frac{\delta\epsilon_v}{\delta\epsilon_\gamma} \end{aligned}$$

$$\left[ \frac{\delta\epsilon_1}{\delta\epsilon_3} \right] = -\frac{(1 - \sin \psi)}{(1 + \sin \psi)}$$

at peak strength  $\psi = \psi_{\max}$  at  $\left[ \frac{\sigma_1'}{\sigma_3'} \right]_{\max}$

at critical state  $\psi = 0$  since volume is constant

**Plasticity: Cohesive material  $\tau_{max} = c_u$  (or  $s_u$ )**

• **Limiting stresses**

Tresca  $|\sigma_1 - \sigma_3| = q_u = 2c_u$

von Mises  $(\sigma_1 - p)^2 + (\sigma_2 - p)^2 + (\sigma_3 - p)^2 = \frac{2}{3} q_u^2 = 2c_u^2$

where  $q_u$  is the undrained triaxial compression strength, and  $c_u$  is the undrained plane shear strength.


Dissipation per unit volume in plane strain deformation following either Tresca or von Mises,

$$\delta D = c_u \delta \epsilon_\gamma$$

For a relative displacement  $x$  across a slip surface of area  $A$  mobilising shear strength  $c_u$ , this becomes

$$D = A c_u x$$

• **Stress conditions across a discontinuity**



Rotation of major principal stress  $\theta$

$$\theta = 90^\circ - \alpha$$

$$s_B - s_A = \Delta s = 2c_u \sin \theta$$

$$\sigma_{1B} - \sigma_{1A} = 2c_u \sin \theta$$

In limit with  $\theta \rightarrow 0$

$$ds = 2c_u d\theta$$

Useful example:


$$\theta = 30^\circ$$

$$\sigma_{1B} - \sigma_{1A} = c_u$$

$$\tau_D / c_u = 0.87$$

$\sigma_{1A}$  = major principal stress in zone A

$\sigma_{1B}$  = major principal stress in zone B



**Plasticity: Frictional material**  $(\tau/\sigma')_{\max} = \tan \phi$

• **Limiting stresses**


$$\sin \phi = (\sigma'_{1f} - \sigma'_{3f}) / (\sigma'_{1f} + \sigma'_{3f}) = (\sigma_{1f} - \sigma_{3f}) / (\sigma_{1f} + \sigma_{3f} - 2u_s)$$

where  $\sigma'_{1f}$  and  $\sigma'_{3f}$  are the major and minor principal effective stresses at failure,  $\sigma_{1f}$  and  $\sigma_{3f}$  are the major and minor principle total stresses at failure, and  $u_s$  is the steady state pore pressure.

Active pressure:  $\sigma'_v > \sigma'_h$   
 $\sigma'_1 = \sigma'_v$  (assuming principal stresses are horizontal and vertical)  
 $\sigma'_3 = \sigma'_h$   
 $K_a = (1 - \sin \phi) / (1 + \sin \phi)$

Passive pressure:  $\sigma'_h > \sigma'_v$   
 $\sigma'_1 = \sigma'_h$  (assuming principal stresses are horizontal and vertical)  
 $\sigma'_3 = \sigma'_v$   
 $K_p = (1 + \sin \phi) / (1 - \sin \phi) = 1 / K_a$

• **Stress conditions across a discontinuity**




Rotation of major principal stress

$$\theta = \pi/2 - \Omega$$

$\sigma_{1A}$  = major principal stress in zone A

$\sigma_{1B}$  = major principal stress in zone B

$$\tan \delta = \tau_D / \sigma'_D$$



$$\sin \Omega = \sin \delta / \sin \phi$$

$$s'_B / s'_A = \sin(\Omega + \delta) / \sin(\Omega - \delta)$$

In limit,  $d\theta \rightarrow 0$  and  $\delta \rightarrow \phi$

$$ds' = 2s' \cdot d\theta \tan \phi$$

Integration gives  $s'_B / s'_A = \exp(2\theta \tan \phi)$

## Empirical earth pressure coefficients following one-dimensional strain

Coefficient of earth pressure in 1D plastic compression (normal compression)

$$K_{o,nc} = 1 - \sin \phi_{crit}$$

Coefficient of earth pressure during a 1D unloading-reloading cycle (overconsolidated soil)

$$K_o = K_{o,nc} \left[ 1 + \frac{(n-1)(n_{max}^\alpha - 1)}{(n_{max} - 1)} \right]$$

where  $n$  is current overconsolidation ratio (OCR) defined as  $\sigma'_{v,max} / \sigma'_v$

$n_{max}$  is maximum historic OCR defined as  $\sigma'_{v,max} / \sigma'_{v,min}$

$\alpha$  is to be taken as  $1.2 \sin \phi_{crit}$

## Cylindrical cavity expansion

Expansion  $\delta A = A - A_o$  caused by increase of pressure  $\delta \sigma_c = \sigma_c - \sigma_o$

At radius  $r$ : small displacement  $\rho = \frac{\delta A}{2\pi r}$


small shear strain  $\gamma = \frac{2\rho}{r}$

Radial equilibrium:  $r \frac{d\sigma_r}{dr} + \sigma_r - \sigma_\theta = 0$

Elastic expansion (small strains)  $\delta \sigma_c = G \frac{\delta A}{A}$

Undrained plastic-elastic expansion  $\delta \sigma_c = c_u \left[ 1 + \ln \frac{G}{c_u} + \ln \frac{\delta A}{A} \right]$

## Infinite slope analysis



$$\begin{aligned} u &= \gamma_w z_w \cos^2 \beta \\ \sigma &= \gamma z \cos^2 \beta \\ \sigma' &= (\gamma z - \gamma_w z_w) \cos^2 \beta \\ \tau &= \gamma z \cos \beta \sin \beta \end{aligned}$$

$$\tan \phi_{mob} = \frac{\tau}{\sigma'} = \frac{\tan \beta}{\left(1 - \frac{\gamma_w z_w}{\gamma z}\right)}$$



## Shallow foundation design

### *Tresca soil, with undrained strength $s_u$*

#### Vertical loading

The vertical bearing capacity,  $q_b$  of a shallow foundation for undrained loading (Tresca soil) is:

$$\frac{V_{ult}}{A} = q_f = s_c d_c N_c s_u + \gamma h$$

$V_{ult}$  and  $A$  are the ultimate vertical load and the foundation area, respectively.  $h$  is the embedment of the foundation base and  $\gamma$  (or  $\gamma'$ ) is the appropriate density of the overburden.

The exact bearing capacity factor  $N_c$  for a plane strain surface foundation (zero embedment) on uniform soil is:

$$N_c = 2 + \pi \quad (\text{Prandtl, 1921})$$

#### *Shape correction factor:*

For a rectangular footing of length  $L$  and breadth  $B$  (Eurocode 7):

$$s_c = 1 + 0.2 B / L$$

The exact solution for a rough circular foundation ( $D = B = L$ ) is  $q_f = 6.05s_u$ , hence  $s_c = 1.18 \sim 1.2$ .

#### *Embedment correction factor:*

A fit to Skempton's (1951) embedment correction factors, for an embedment of  $h$ , is:

$$d_c = 1 + 0.33 \tan^{-1} (h/B) \quad (\text{or } h/D \text{ for a circular foundation})$$

#### Combined V-H loading

A curve fit to Green's lower bound plasticity solution for V-H loading is:

$$\text{If } V/V_{ult} > 0.5: \quad \frac{V}{V_{ult}} = \frac{1}{2} + \frac{1}{2} \sqrt{1 - \frac{H}{H_{ult}}} \quad \text{or} \quad \frac{H}{H_{ult}} = 1 - \left( 2 \frac{V}{V_{ult}} - 1 \right)^2$$

$$\text{If } V/V_{ult} < 0.5: \quad H = H_{ult} = B s_u$$

#### Combined V-H-M loading

With lift-off: combined Green-Meyerhof

$$\text{Without lift-off: } \left( \frac{V}{V_{ult}} \right)^2 + \left[ \frac{M}{M_{ult}} \left( 1 - 0.3 \frac{H}{H_{ult}} \right) \right]^2 + \left| \left( \frac{H}{H_{ult}} \right)^3 \right| - 1 = 0 \quad (\text{Taiebet \& Carter 2000})$$

### Frictional (Coulomb) soil, with friction angle $\phi$

#### Vertical loading

The vertical bearing capacity,  $q_B$  of a shallow foundation under drained loading (Coulomb soil) is:

$$\frac{V_{ult}}{A} = q_f = s_q N_q \sigma'_{v0} + s_\gamma N_\gamma \frac{\gamma' B}{2}$$

The bearing capacity factors  $N_q$  and  $N_\gamma$  account for the capacity arising from surcharge and self-weight of the foundation soil respectively.  $\sigma'_{v0}$  is the in situ effective stress acting at the level of the foundation base.

For a strip footing on weightless soil, the exact solution for  $N_q$  is:

$$N_q = \tan^2(\pi/4 + \phi/2) e^{(\pi \tan \phi)} \quad (\text{Prandtl 1921})$$

An empirical relationship to estimate  $N_\gamma$  from  $N_q$  is (Eurocode 7):

$$N_\gamma = 2 (N_q - 1) \tan \phi$$

Curve fits to exact solutions for  $N_\gamma = f(\phi)$  are (Davis & Booker 1971):

$$\text{Rough base: } N_\gamma = 0.1054 e^{9.6\phi}$$

$$\text{Smooth base: } N_\gamma = 0.0663 e^{9.3\phi}$$

#### Shape correction factors:

For a rectangular footing of length  $L$  and breadth  $B$  (Eurocode 7):

$$s_q = 1 + (B \sin \phi) / L$$

$$s_\gamma = 1 - 0.3 B / L$$

For circular footings take  $L = B$ .

#### Combined V-H loading

The Green/Sokolovski lower bound solution gives a V-H failure surface.


#### Combined V-H-M loading

With lift-off- drained conditions - use Butterfield & Gottardi (1994) failure surface shown above

$$\left[ \frac{H/V_{ult}}{t_h} \right]^2 + \left[ \frac{M/BV_{ult}}{t_m} \right]^2 + \left[ \frac{2C(M/BV_{ult})(H/V_{ult})}{t_h t_m} \right] = \left[ \frac{V}{V_{ult}} \left( 1 - \frac{V}{V_{ult}} \right) \right]^2$$

$$\text{where } C = \tan \left( \frac{2\rho(t_h - t_m)(t_h + t_m)}{2t_h t_m} \right) \quad (\text{Butterfield \& Gottardi, 1994})$$

Typically,  $t_h \sim 0.5$ ,  $t_m \sim 0.4$  and  $\rho \sim 15^\circ$ . Note that  $t_h$  is the friction coefficient,  $H/V = \tan \phi$ , during sliding.



1. (a) –  
 (b) –  
 (c) (i) –  
 (ii) –  
 (iii)  $\tau_{peak} = 183 \text{ kPa}$ ,  $\tau_{crit} = 145 \text{ kPa}$ ,  $e_{crit} = 0.791$   
 (iv)  $\tau_u = 98 \text{ kPa}$ ,  $\Delta u = 15 \text{ kPa}$
  
2. (a) (i)  $q_f = 126 \text{ kPa}$ ,  $\varepsilon_v = 7.4\%$   
 (ii)  $q_f = 127 \text{ kPa}$ ,  $\varepsilon_v = 9.4\%$   
 (b) (i)  $q_f = 94.3 \text{ kPa}$ ,  $\Delta u = 25.5 \text{ kPa}$   
 (ii)  $q_y = 97.8 \text{ kPa}$   
 (iii)  $p = 196 \text{ kPa}$
  
3. (a) 25 mm  
 (b) –  
 (c) 2.9 m  
 (d) 165 kPa
  
4. (a) (i)  $\sigma_v = 600 \text{ kPa}$ ,  $\sigma_h = 474 \text{ kPa}$ ,  $\sigma'_v = 300 \text{ kPa}$ ,  $\sigma'_h = 174 \text{ kPa}$   
 (ii)  $OCR = 2.73$ ,  $\sigma_v = 200 \text{ kPa}$ ,  $\sigma_h = 189 \text{ kPa}$ ,  $\sigma'_v = 110 \text{ kPa}$ ,  $\sigma'_h = 99 \text{ kPa}$   
 (iii) –  
 (b) -34.5 kPa  
 (c) 9.5 kPa